

# Manual – Polar 65

## What's Included

- Keyboard
- USB Cable
- Keycap/Switch Puller Tool

## Configuring “Continuous Rapid Trigger Mode”

### Step 1

Press **FN + TAB** to enter configure mode. Keyboard backlight will turn purple



### Step 2

Set keyboard sensitivity up to 20 levels with the highlighted keys below.



Toggle Mode

Reset to default setting

Increase sensitivity

Decrease sensitivity

- **Toggle Mode** – Switch between GLOBAL and PER-KEY layers.
  - Global Layer (Purple) – Adjusts all keys together
  - PER-KEY Layer (Red) – Adjusts only the keys selected in red
- **Reset to Default** – Will go back to default setting of the active layer mode
- **Increase Sensitivity** – Makes key actuate faster. The brighter the lighting, the faster the actuation
- **Decrease Sensitivity** – Makes key actuate slower. The dimmer the lighting, the slower the actuation

### Step 3

Press **FN** to save the setting and exit configure mode.



## RGB Functions

|                  |                                |
|------------------|--------------------------------|
| FN + Enter       | Change RGB Mode (16 Effects)   |
| FN + Arrow Left  | Decrease light effect speed    |
| FN + Arrow Right | Increase light effect speed    |
| FN + Arrow Up    | Increase brightness            |
| FN + Arrow Down  | Decrease brightness            |
| FN + R Shift     | Color Switch (7 Preset Colors) |

## FN Key combination function list

|                              |   |
|------------------------------|---|
| FN + 1,2,3,4,5,6,7,8,9,0,-,= | F1 – F12  |
| FN + `~                      | Insert  |
| FN + [                       | Volume -  |
| FN + ]                       | Volume +  |
| FN + \                       | Mute  |
| FN + P                       | Play / Pause  |
| FN + I                       | Back Track  |
| FN + O                       | Skip Track  |
| FN + PgUp                    | Home  |
| FN + PgDn                    | End   |
| FN + Del                     | Print Screen  |
| FN + Win Key                 | Game Mode (Win Key Lock)  |
| FN (Hold for 3s)             | Function Lock<br>On = White Solid LED on FN Key<br>Off = No White Solid LED on FN Key |
| FN + Tab                     | Continuous Rapid Trigger Mode   |
| FN + ESC (Hold for 5s)       | Factory Reset   |