















PART LIST

A :Side Panel	B : Top Tray	C:Bottom Tray	D:Front Connector
2 PCS	1 PC	1 PC	1 PC
			
E:Removable Tray With Compartments	F: Removable Tray	G:Side Pocket	H: Back Panel
2 PCS	2 PCS	2 PCS	1 PC
			
I: Door With Lock	J: Wheel	K: 4X8mm Bolt	L:8X12mm Bolt
2 PCS	4 PCS	2 PCS	8 PCS
			
M:Dryer Holder	N:Tool		
1 PC	1 PC		
			

OmySalon

Salon Trolley


ST1802




Visit our website: www.omysalon.com

For missing parts or questions: email us at support@omysalon.com


INSTALLATION




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7



STEP 8



STEP 9



STEP 10