


HAIR STYLING STATION

USER MANUAL



Thanks for purchasing OmySalon hair styling station. Please feel free to contact us if you have any problems with assembly or other after-sale issues. OmySalon customer service team is here to assist you. Email: support@omysalon.com; Website: www.omysalon.com. Please attach your user name or order ID so that we can serve you better.

AWARNING






Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.
- Do not defeat or remove the drawer interlock system.


This is a permanent label.

Do not remove!


| | | Ø8*40 | Ø5*40 | Ø3.5*14 |
|----------------|---------|----------|---------|--------------------|
| A*59 | B*59 | C*21 | D*2 | E*52 |
| Ø4*35 | Ø3.5*16 | Ø3*14 | C(4*19) | € Ø8*60 € Ø6*80 |
| 24 33 | Ø3,5°10 | Ø3°14 | Ø4*18 | |
| F*8 | G*1 | H*1 | I*3 | J*6 |
| | | M2 M1 | | Ø20 |
| K*12 | L*2 | M*2 | N*2 | O*59 |
| Ø4*14 Ø4*35 | Ø60 | 0 | | |
| P*1 | Q*3 | R*4 | S*4 | |









A*8+C*7+E*4+M1*1




A*8+C*2+E*4+M1*1




C*12







B*10





D*1


6














B*11




B*4+R*4




E*6+K*6




A*16



B*8




B*8





E*6+K*6


16





B*4

















B*8+F*8+I*2

22



E*8+M2*2





E*12+S*4

