
CHARGING THE CAMERA AND TAG

1. Assemble the Power Cord

Plug the USB end into the wall adapter.

One end has a USB, while the other a mini USB.




2. Charge your Camera

Plug the mini USB end of the power cord into the Camera Base.

The mini USB connects to the smaller charging port on the left, under the rubber cover.

You will see a red light at the top of the touch screen on the back of the Camera confirming that the Camera is charging.



3. Charge your Tag

Confirm that the Tag is docked into the Tag charger on the front of the Camera Base.

The Tag will charge automatically when the Camera is charging.

The Tag needs to be off while charging.



4. Charge Time

Fully charge the Camera and Tag before use.

This will take about 4 hours.

Charging time varies based on your wall adapter rating.