

Thank you for your purchase. Please take a moment to read the instructions below, If you have any questions, feel free to email us at info@millnertools.com.

Millner-Haufen Tool Co. 4 ½” Diamond Grinding Wheels are unique in design and functionality. When used correctly, the diamond wheel can cut, grind and sand. In general, angle grinders spin in excess of 10,000 rpm. Improper use can create a dangerous situation. Please follow the precautions and techniques below.

- Unplug grinder when you're attaching or changing wheels.
- Attach handle and maintain a firm grip with both hands.
- Always use protective guard.
- After installing your new Millner-Haufen Grinding Wheel, run grinder for one minute in a protected area before use, in order to make sure everything is secure and functioning properly.
- Orient work so debris is directed downward.
- Orient work so the wheel spins away from, not into, sharp edges. This will minimize the possibility that the wheel catches and throws the work piece or causes the grinder to kick back.
- Clamp or secure the work piece if it is not mounted securely already.

WARNING- Always use safety glasses and protective gear when using and/or around power tools. MAX SPEED- 15,000 rpm

Excellent for cutting ferrous metal, tile, stone, concrete, stucco, cement, old mortar, re-bar, restoring cutting edges, auto body repair, marine repair, spot welds, welded joints and much more!