












<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>	<b>G</b>	<b>H</b>	<b>I</b>
20PCS	20PCS	16PCS	4PCS	2PCS	3PCS	3PCS	3.5*14 32PCS	3.5*30 6PCS

<b>J</b> 4*50 6PCS	<b>K</b> 6PCS	<b>LED</b> 1PCS	
--------------------------	------------------	--------------------	--




1			
	1800*400 1PC	1800*400 1PC	400*268 1PC
5			
	400*268 1PC	898*150 1PC	898*150 1PC
8			
	898*60 1PC	898*60 1PC	884*233 1PC
11			
			884*233 1PC

1




	A*20
	C*16

②




	B*12
	F*3
	I*6

③




	B*8
	D*4
	E*2
	G*3
	H*32
	J*6
	K*6








④

The following  
installation LED  
lights



led



After the installation was complete,  
remove the plastic gasket on the remote  
control, then align the sensor on the LED  
light for remote operation.