

# VUBER® PULSE PRO

## SMART BATTERY



SCAN QR CODE  
FOR EXPANDED  
MANUAL

### USER MANUAL



## PACKAGE CONTENTS:

- PULSE PRO battery
- USB-C charging cable
- 1x "Crown" 510 magnetic adapter
- 1x "Flat" magnetic adapter
- User Guide

## **PRODUCT OVERVIEW**

Experience the ultimate in control, power, and taste with the Pulse Pro smart battery. Featuring exclusive draw-down technology, this is our most powerful and feature-packed 510 battery. Patented "Never Burn" ensures you get the most out of your cartridge. Unlock the full flavor from your cartridges with the Pulse Pro!

## KEY FEATURES:

- Adjustable voltage/temperature settings with Vuber's "Never Burn" technology
- Backlit OLED display with battery life
- Dual puff counters
- Wireless & USB-C charging
- Magnetic cartridge adapters

# PRODUCT OVERVIEW



# OLED SCREEN DETAIL



# **GETTING STARTED**

## **BATTERY CHARGING:**

1. Connect the included USB-C cable to the charging port on the bottom of the PULSE PRO.\*
2. Plug the other end of the cable into a USB-compatible power source (e.g., a computer or USB wall adapter).
3. Disconnect the charging cable when the battery is fully charged.

\*The PULSE PRO can also be charged via wireless charging. Simply place the PULSE PRO flat (with the Vuber logo facing up) on a wireless charger. The OLED screen will illuminate, indicating that the battery is charging.

## **POWERING ON/OFF:**

To turn the battery on or off:

- Click the power button rapidly five times in succession. The OLED screen will illuminate.
- Click the power button five times to turn the PULSE PRO off.

# GETTING STARTED

## CARTRIDGE ATTACHMENT:

The PULSE PRO uses a magnetic connection to ensure that your cartridge is securely connected to the battery.

Two magnetic adapters are included:

- "Crown" Adapter - use with standard diameter cartridges (most 510 carts).
- "Flat" Adapter - use with larger diameter cartridges that will not fit the "Crown" adapter.

1. Select the appropriate adapter for your cartridge. TIP: Most cartridges will use the "Crown" adapter.
2. Carefully screw the cartridge onto the selected adapter.
3. Gently place the cartridge and adapter down into the cartridge chamber; it will magnetically "lock" into place.

## **HOW TO USE**

### **AUTOMATIC MODE:**

The PULSE PRO's default mode is automatic mode, powered by "Never Burn" technology. Based on the resistance read from the cartridge, the PULSE PRO will automatically select the voltage for optimal use.

After attaching the cartridge, follow these steps to vape:

1. Turn on the PULSE PRO.
2. Press and hold the Power/Draw button while inhaling through the cartridge mouthpiece.
3. Release the power button after inhaling.

When a cartridge is connected, the screen will display the selected temperature. the PULSE PRO will return to the initial temperature setting, after releasing the power button.

## **HOW TO USE**

### **MANUAL/PRO MODE:**

The PULSE PRO temperature/voltage can be precisely adjusted to your preferred level, while still utilizing the “Never Burn” technology. To adjust the temperature:

1. Press the “Power/Select” button three times rapidly.
2. The PULSE PRO temperature will flash on the display, indicating that it is in “Manual” mode.
3. Press the “Up” button to increase the temperature level. Press the “Down” button to decrease the temperature level.
4. Once the desired temperature level is reached, press the “Power/Draw” button once to confirm and set the temperature.
5. Press the “Power/Draw” button while inhaling on the cartridge mouthpiece to produce vapor.

## **HOW TO USE**

### **ADDITIONAL SETTINGS/FUNCTIONS:**

To view additional settings, press the "Down" button once - the screen will then show the Voltage, Wattage, Resistance, and session puff counter, as well as the current battery life.

To reset the session puff counter:

1. Press the "Down" button once to display the secondary screen.
2. Press and hold the "Down" button for three seconds, then press the "Down" button once to reset the counter.
3. Press the "Power/Draw" button to return to the main screen.

The temperature on the PULSE PRO can also be set to Celsius. Press the "Power/Draw" button two times to change between °F and °C modes.



## **CLEANING & CARE**

### **CLEANING THE BATTERY:**

Keep the PULSE PRO clean and free from any liquids or residue to maintain its optimal performance.

Cartridges may accumulate residue with use. Clean the mouthpiece and the exterior of the cartridge with cotton swab or cloth with a small amount of isopropyl alcohol.

Use a cotton swab or soft cloth lightly dampened with a small amount of isopropyl alcohol to clean the battery exterior and connectors.

It is recommended to clean the magnetic adapter(s) and battery connection after each session. If the battery is not in regular use, it is recommended to store the battery and the cartridge separately.

## **CLEANING & CARE**

### **TROUBLESHOOTING:**

The PULSE PRO was designed to be used with 510 cartridges, but not all cartridges are made the same. The PULSE PRO will display error messages on the OLED display if there is a connection error with the attached cartridge:

- **NO ATOMIZER** - There is a connection issue with the cartridge. Make sure the cartridge and magnetic adapter are clean and free of debris. Ensure that the cartridge is not over-tightened in the magnetic adapter. Try to loosen the connection between the adapter and cart by a quarter turn counter-clockwise.
- **SHORTED** - There is an issue with the cartridge and the battery can not make a proper connection. Try the same steps as the NO ATOMIZER message.

## **CLEANING & CARE**

### **TROUBLESHOOTING** (continued):

- **SHORTED (continued)**  
If you attempt the outlined steps and still receive the SHORTED error, please contact Vuber Support.
- **LOW BATT** - The battery is low and will not function until recharged. Connect to supplied USB-C cable or place battery on wireless charger.

### **SAFETY PRECAUTIONS**

- Do not expose the battery to extreme temperatures.
- Keep the battery away from water or any liquids.
- Use only compatible vaping cartridges and accessories.
- Do not charge the battery unattended or overnight.
- If the battery becomes hot to the touch, discontinue use and contact Vuber Support.

# LIMITED LIFETIME WARRANTY

Vuber Technologies is proud to offer a limited lifetime warranty on all Vuber devices. To qualify for a warranty claim, register your product within 30 days of purchase. To register products or submit a warranty claim, please visit us at [VuberVaporizers.com](http://VuberVaporizers.com)

- Approved warranty claims are typically processed within 3-5 business days.
- A shipping and handling fee applies to EACH item being warrantied.
- Cartridges, atomizers, and heating coils will need to be replaced over times, and are not covered under warranty.
- Please retain your receipt to qualify for warranty replacement.
- Instruction videos are available under each product page on [VuberVaporizers.com](http://VuberVaporizers.com)
- Damage caused by improper use, physical abuse, moisture exposure, or any activity other than vaping will not be covered under warranty.
- Loss and theft are not covered under warranty.

