



VUBER®
BUTANE-POWERED
TORCH
USER GUIDE

VUBER® views vaporization as the efficient way to utilize your preferred product for medical and recreational purposes. We take pride in offering portable, convenient, and discreet delivery systems.

The TORCH is a butane-powered heat source that can be used for a wide variety of applications. It features a large fuel tank, adjustable flame dial, safety lock, and easy push button start.

This torch is used with a flammable product. Failure to comply with these Warnings and Instructions may result in an explosion or fire that may cause property damage, serious personal injury or death.

Read and comply with the instructions and warnings in this manual and familiarize yourself with the torch before lighting and using. Review instructions and warnings periodically to maintain awareness.

Do not try to operate before reading instructions.

EXTREMELY FLAMMABLE. CONTENTS UNDER PRESSURE.


- Take precautions not to heat fuel tank.
- Contains flammable gas under pressure. Do not expose the torch or fuel to temperatures exceeding 120°F/49°C or prolonged sunlight.
- Never use torch in or around flammable fumes, liquids, or explosive materials.
- Never pierce fuel tank or expose torch to fire.
- Do not breathe gas, fumes, vapor or spray. If inhaled, remove affected person to fresh air.
- Avoid contact with eyes or skin. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. For skin contact, flush with large amounts of water.

- Do not modify torch in any way. Do not alter factory settings. Serious injury or death can result from adjusting factory settings or modifying factory fitted parts.
- Read and understand refueling instruction before refueling torch. Refueling the torch incorrectly can result in serious injury or death.
- Keep torch out of reach of children and anyone who has not read instructions. Do not point torch towards face, other persons or flammable objects. Never attempt to use torch as a cigarette lighter.
- Eye protection is recommended when using the torch.
- To avoid risk of damage to torch, always protect torch from impact and never allow torch to drop onto floor or hard surfaces. Never use a torch that appears to be damaged.
- Do not use a leaking, damaged or malfunctioning torch. If torch is leaking, contact manufacturer or retailer.
- Ignite torch away from face, hands, clothing, or other flammable material.
- Use caution when operating the torch outdoors on sunny or windy days. Bright sun makes it impossible to see the torch's flame. Wind may carry the torch's heat back towards you or other areas not intended to be heated. Windy conditions may also cause sparks to be blown into other areas with combustible materials.
- Burner nozzle and tip assembly become extremely hot during use and remain hot after extinguishing the torch. Do not touch torch tip until torch has cooled.
- Never use the torch on or near combustibles (fuels, rags, towels, paper products, etc.). Be careful around motor vehicles or any gasoline-fired products and beware of hidden fuel lines and tanks.
- Be sure the torch is not pointed in a direction which could cause nearby objects to ignite when the torch is set down.

- Never leave the torch unattended when lit.
- Never attempt to repair or heat a gasoline tank, a chemical drum an aerosol can, a compressed gas container that held flammable liquid or gas or any other chemical. Heating these is extremely dangerous, especially after they have been “emptied”.
- Department of Transportation Hazardous Materials Regulations forbids the carriage of butane or other flammable gas products on passenger aircraft. Do not pack this item or any other flammable gas item in any checked or carry-on baggage.
- Make sure torch is completely extinguished after use.
- Ensure that torch is completely cool before storing.

FILLING/RE-FILLING THE TORCH

1. Use only genuine Butane fuel when refilling torch.
2. Ensure that the torch is extinguished before refilling.
3. Allow sufficient time for torch to cool to room temperature before refilling the torch with fuel.
4. Refill torch in a well-ventilated area free of fire or other sources of ignition and away from people.
5. Never smoke while refilling the torch.
6. Hold the torch with the FILL VALVE (A) up.
7. Invert fuel canister and insert the fuel canister tip into the FILL VALVE (A).
8. Push the fuel canister and torch together to allow fuel to flow into the torch fuel tank. Torch should be filled in about 10 seconds.
9. Stop refilling once the fuel begins to overflow.
10. Wait 3 minutes to allow fuel gas to stabilize before igniting the torch.



Lighting and Operation

1. Turn FLAME ADJUSTMENT KNOB (C) approximately halfway between (-) and (+) position.
2. Press and hold down the IGNITION BUTTON (B).
3. Repeat step 2 if torch does not ignite.
4. Release IGNITION BUTTON (B) to extinguish torch.



Adjust Flame

1. Slide FLAME ADJUSTMENT KNOB (C) towards "-" (left) for smaller flame.
2. Slide FLAME ADJUSTMENT KNOB (C) towards "+" (right) for larger flame.

Safety Lock

1. Slide SAFETY LOCK (D) towards "🔒" to lock the IGNITION BUTTON (B).
2. Slide SAFETY LOCK (D) towards "🔓" to unlock the IGNITION BUTTON (B).

WARNING: Do not engage the lock while the torch is in operation with an active flame.

VUBER[®]
VENTURE HIGHER

Check out the full line of Vuber products at:
www.VuberVaporizers.com

