



These diagrams are a general guidance and reference to the machine you have hired off HVWH.

The dimensions of the machines hired from HVWH may differ, therefore the diagram supplied should be a general rule of thumb. HVWH take no responsibility for overloading the machine, the incorrect loading of material upon the machine, mis-using the machine incorrectly and all damages and injuries that may occur of doing such things.

What will be incorrect use of such machine that does eventuate in damages or injury, is within HVWHs' discretion to determine.