		Pum	Pump 4-771		
Schematic #	Part #	Description	Schematic #	Part #	Description
1	9751		25		7362 Filler/Gooseneck Gasket
2		7550 Wrench	26		7355 Filler Body
3		Screw	27		7353 Special Nut
4		7554 Wrench bracket	28		7350 Filler/Gooseneck O-ring
5		7364 Lock Nut	29		7168 S-Hook
9		9334 Pump Link	30		7358 Filler Cable
7		7553 Black Plastic Washer (Link)	31		7356 Discharge Tube
8		7555 Metal Link Washer	32		7321 Piston Rod
6		7363 1/4-20 X 2 Hex head screw	33		7329 Valve Disc
10		7622 Small Release Pin	34		7359 Small Retainer
11	7622	7622 Small Release Pin	35		7328 Piston Cup
12	7347 Ball	Ball	36		7327 Large Retainer
13		7128 Pump Ball Screw	37		7360 Lock Clip
14		7738 Pump Handle	38		7343 Lock Nut
15		Bolt	39		7625 Small Screw
16		7342 Lock Washer	40		9623 Pump Latch
17		7633 Pump O-ring	41	9624	9624 Pump Tube
18		9635 Pump Head	42		9916 Wing Nut
19		7324 U-Cup	43		7556 Metal Washer
20		7323 Brass Nut	44		7557 Foot Valve Spacer
21		7345 Brass Nut Bearing	45		7621 Long Release Pin
22		Bolt	46		9330 Pump Tube Foot
23	7326 Nut	Nut	47		7558 Screw
24		7352 Stud Screw	48		9348 Screen

