



Using Netflix on your Bathroom Smart TV

Please read this guide before using Netflix on your new television. This will inform you on how to operate key functions.

You will require the email address & password registered to your Netflix account. If you do not have an account, we recommend that you do to www.netflix.com and register via the web.

Logging in

On first time logging in to Netflix after downloading it, you will be faced with the intro screen and will have to log in to use the app.

To log in, you will need to access the 'Sign In' area.

1. On the TV remote, press the Blue circle button. This will switch the TV to 'mouse mode' and a cursor will appear on the screen
2. Use the arrow buttons to move the cursor up to the 'Sign In' button at the top right
3. This will take you to the next screen to enter your email address and password and bring up a keyboard automatically. Use the arrow keys to operate the on-screen keyboard

Navigating the 'Download & Go'

After logging in, you will have a prompt screen on the 'Download & Go' functionality of Netflix.

To navigate past this:

1. On the TV remote, press the Blue circle button. This will switch the TV to 'mouse mode' and a cursor will appear on the screen
2. Use the arrow buttons to move the cursor down to 'OK' option and press the Enter button on the remote

You will now be on the Netflix home screen

Navigating the Categories

Netflix relies on a row format to separate different categories.

To scroll through the categories:

1. On the TV remote, press the Blue circle button twice. A small graphic will appear at the bottom right with 4 directional arrows.
2. Use the Up & Down arrow buttons on the remote to scroll between the different categories
3. Use the Left & Right arrow buttons on the remote to scroll through a category to see all of the available shows

Selecting a show

To select a show to watch

1. On the TV remote, press the Blue circle button. This will switch the TV to 'mouse mode' and a cursor will appear on the screen
2. Use the arrow keys to navigate to a show you want to watch
3. Press the enter button on the remote to select it.