LITHIUM 4WD KIT Wiring Diagram

Cables used to link batteries and Cable B- to Battery 1 must be the same guage (or better) as the cables used for connecting loads. E.g 1000W Inverter requires 8 AWG, then all cables must be atleast 8 AWG.

All positives from load/chargers to Battery 1

