



HOW TO: **Dynaplug**[®] (re)LOAD AND USE YOUR NEW **RACER**

FIRST: ROLL PLUG BETWEEN YOUR THUMB AND FOREFINGER TO NARROW ITS DIAMETER BEFORE LOADING.

* DO NOT HOLD BRASS TIP WHILE ROLLING



SECOND: SLIDE PLUG INTO INSERTION TUBE UNTIL BRASS TIP IS FLUSH AGAINST THE TUBE




* IF PLUG IS TOO STICKY OR WON'T FIT IN THE TUBE, RE-ROLL & APPLY SOME SALIVA/WATER TO LUBE THE PLUG. YOU CAN ALSO CLEAN THE TUBE WITH A PIPE CLEANER + RUBBING ALCOHOL.

REPAIRING A PUNCTURE → BACK TO SHREDDING

*** TIPS AND TRICKS ***
 • SOMETIMES IT TAKES MULTIPLE PLUGS TO SEAL A GNARLY PUNCTURE.
 • AFTER YOU PLUG, SPIN YOUR WHEEL TO SPREAD THE SEALANT AROUND.


STEP 1:
FIND THE PUNCTURE
LISTEN FOR THE HISSSS...

* USE YOUR FREE HAND TO KEEP AIR FROM ESCAPING.




STEP 2:

ALIGN TOOL WITH THE PUNCTURE




STEP 3:
PUSH TOOL ALL THE WAY THROUGH PUNCTURE




STEP 4:

PULL TOOL FROM PUNCTURE. PLUG WILL REMAIN IN THE TIRE. ONCE LEAK STOPS, TRIM PLUG, & ADD AIR.



* IF NEEDED

MADE IN CHICO CA!
PATENT # 8,707,829 * 2021



LIMITED
LIFE TIME
WARRANTY