



Mini Portable Bluetooth Speaker User Manual

Contact: sales@cruzentunes.com
Phone: 844-278-9366

Introduction:

Thank for choosing the B7-S-10 Speaker. It is small, portable, and easy to operate. It can not only play stereo music but also use as a hands-free phone. It supports radio function, and can make wireless connection with most bluetooth devices and also connects with audio devices via 3.5 mm stereo audio cable. The bluetooth devices which are paired with the speaker must support bluetooth A2DP (Advanced Audio Distribution Profile), and AVRCP (Audio Video Remote Control Profile), otherwise it can't set up the connection with bluetooth devices and play stereo music.

Specification:

Bluetooth ver. V2.1+ EDR dist. 32ft. or 10m
Bluetooth protocol: A2DP/AVRCP/HFP
Battery: 400 mAh built in lithium
Frequency Response 100-20kHz
Chg Time: 2-3 Hrs.- Play 4-5 Hrs @ 70%
Prod. Size dia 60mm H 50mm
operating temp -10°C= 40°C

Accessories:

User manual 1pc.,
Micro USB cable 1 pc.
3.5mm Audio cable 1 pc.

Warranty: One year all parts

Charging:

Connect the speaker to a computer, tablet using the supplied USB charging cable or a power adapter (5V) for charging. The red status indicator will keep on light while charging and will turn off when charging is complete.

When it is in low battery state, the red light status indicator will keep on flashing. Recharge speaker.

Before using the speaker for the first time, you must completely charge the battery. ♦ NOTE: do not place the battery directly in the sunshine for a long time, fire and other hot environment.

Pairing:

Before using speaker, you must first pair the speaker to your bluetooth device. To pair the device, first slide the power switch to "ON". The status indicator should blink rapidly with blue and red lights. Use your device bluetooth menu to activate devices searching (refer to your device manual). Choose the displayed device 8800 ID. listing to pair. If password window pops up, enter password "0000" (four zeros) and click pair. It will pair automatically between speaker and bluetooth device. If pair is successful, the status indicator should change to a gentle blinking blue light. If pairing is unsuccessful, slide the power switch to "OFF" then back "ON" and retry the pairing process.

Radio

Press "M" to switch the status from bluetooth to radio, and then a short press "▶||" to automatically search channels and the red light will flash quickly. Once the searching is finished, the speaker will be automatically back to the first channel. You can press "+/-" quickly to skip channels.

Music Play Back:

When you use the speaker as an audio output device, you can control the playback from the speaker or your device. A short press +/- to skip track. Short press ▶|| to pause or resume playback. A long press +/- to adjust volume up or down. NOTE: these buttons will have no effect when you are using the aux-in audio port.

Answer/End/Recall:

If your bluetooth device can receive phone calls, your ring tone may interrupt your music playback and be heard from the speaker. You can answer and end the call as you like.

Answer call: When there is an incoming call you need to answer, the speaker will have a ring-tone. Just press ▶|| to start the phone conversation.

End Call: During the phone answering status, again press ▶|| to end the call.

Recall: It will recall the last number you called after press ▶|| twice.

Aux-In audio input:

You can also connect a non-bluetooth audio device (like a MP3 player or CD player) to your speaker via the supplied 3.5 mm audio cable.

Just connect the cable or similar 3.5 audio cable to your audio device through 3.5 port. When a cable is connected to the aux-in port, the bluetooth feature will not operate, disconnect the cable to reactivate the bluetooth feature.

Troubleshooting tips:

♦ If you are having trouble pairing the speaker to your device. First ensure the power switch is in the "ON" position.
♦ Then check to see if the status indicator is rapidly blinking both blue and red lights; if not, turn the speaker to "OFF" then "ON" again.
♦ If the status indicator remains dark when you turn the power switch "ON" the speaker needs to be charged.

♦ Your device needs to have bluetooth active and it needs to actively searching for new devices.
♦ Some bluetooth-equipped devices do not carry the A2DP profile. Your device needs to be equipped with the A2DP for audio playback and the HFP profile for speakerphone use.
♦ The distance between your device and the speaker may need to be less than 32 feet (10 meters) for pairing. It may be optimal to keep your device next to the speaker.

Cautions:

♦ Keep the speaker from children, this product is not a toy.
♦ Do not drop, toss speaker or use excessive force when operating.
This product is not waterproof and not to be used in water or in areas of excessive moisture.
♦ Keep the speaker away from excessive heat or cold. Do not expose it to direct sunshine. Avoid operating or storing the battery near fire, stove, or inside a sealed car in hot weather.
♦ The built-in lithium-ion battery must not be exposed to flame or excessive heat. Exposing it to fire may cause the battery to generate heat, ignite or explode. For your safety, do not attempt to remove or modify the battery.
♦ The speaker and its battery should not be disposed as a municipal solid waste. To recycle it, contact your local hazardous waste processor to find the nearest drop-off location for lithium-ion batteries.