

CruZen X Grip Tether Instructions (Optional)

Recommended for all outdoor rough terrain use.
Split CZ 29 or CZ30 apart insert the tether between parts re-install center screw and tighten down. Insert phone in x grip wrap the tethers four corners around phones four corners.



CruZen Bicycle Accessories
www.cruzentunes.com
sales@cruzentunes.com
844-cruzenn 278-9366

CZ 40-tether

