comfortel


lambert wash lounge

#1475

LAMBERT SHAMPOO LOUNGE

#1475.01

LAMBERT BASIN STAND WITH WHITE BASIN



GENERAL SAFETY

- 1. Read carefully and keep these instructions in a safe place.
- Use this product only for its intended function and do not use attachments not recommended by the manufacturer.
- 3. Do not use outdoors.

PLUMBING

1. This unit must be plumbed by a licensed plumber.


ALL PLUMBING MUST BE COMPLETED BY A LICENSED PLUMBER

🚹 IMPORTANT


DO NOT ALLOW CHILDREN AROUND THE WASHLOUNGE WHEN IN USE

877[34.5]


GET STARTED



POSITIONING



If washing from behind, allow a minimum of 400mm of space behind your washlounge to provide room for access.



If washing from side add 400mm between each basin. All measurements in mm.

BEFORE INSTALLING YOU SHOULD CONSIDER THE FOLLOWING

- Allow for the necessary room around the unit for free movement.
- If installing against a wall, a minimum distance of 80mm between wall and bottom back of basin.
- If plumbing location is in wall (see Diagram A).
 For neatness of finish it is preferable to bring water and waste into the washlounge in the same hole.
- If plumbing location is on floor (see Diagram A), place washlounge over.

PLUMBING ACCESS OPTIONS Determine the best way to connect plumbing.


OPTION A: FROM WALL TO BASIN STAND From behind the basin stand connect plumbing to the wall


OPTION B: FROM FLOOR IN BASIN STAND From the basin stand connect plumbing to the floor

ALL PLUMBING MUST BE COMPLETED BY A LICENSED PLUMBER

GET STARTED

BEFORE INSTALLATION OF PLUMBING SECURE AND BOLT DOWN BASIN STAND










THE WASHLOUNGE MUST BE SECURED TO THE FLOOR.

Making sure your wash lounge is secure to the floor using appropiate fixings (not supplied).

INSTALLATION & ASSEMBLY: BASIN STAND WITH XL BASIN



BASIN ASSEMBLY


- 1. Flick Mixer
- 2. Shower head
- 3. Showerhose basin collar
- 4. Comfortneck
- 5. O-ring
- 6. Foam washers
- 7. Plastic nut
- 8. Flat seal
- 9. Fitted flange

- **10.** Flexible waste pipe
- 11. Flange
- 12. Seal
- 13. P trap (not supplied)
- 14. Hot and cold braided hoses
- 15. Long nut
- 16. Plastic washers
- 17. Metal washers
- 18. O-rina

- 1. Washlounge MUST be secured to the floor. Secure to the floor using appropiate fixings
- 2. Remove washer & springs from the basin
- 3. Install basin into stand and re-intall the washer & spring back into place and tighten.

TAP SET & HOSE INSTALLATION

- 4. Install Flick Mixer using O-ring, plastic and metal washers & (Long Nut) and Shower Head using the Showerhose Basin Collar, O-ring, Foam Washer & Plastic Nut as indicated.
- 5. Place Flick Mixer and Shower Hoses through the holes in the basin.
- PLUMBING CONNECTION
- 6. Connect PVC pipe (not supplied) and P trap (not supplied) to 40mm Plug & Waste (supplied) already installed in the basin.
- 7. Connect hot and cold (1/2" connection) braided hoses to respective supplies.



ASSEMBLY

1. Install the lounge seat and fix with screws supplied.



We recommend while assembling the washlounge according to the assembly order, fix screws and nuts, however do not tighen in full.

Once the washlounge is fully assembled, adjust the balance of the chair and lock each screw tight.

CLEANING

UPHOLSTERY

All upholstery needs some care; good housekeeping will help to prolong the life of any upholstered products. Avoid extreme temperatures. Extreme cold can make your vinyl prone to cracking, while extreme heat can cause permanent stretching. Avoid exposing your products to direct sunlight for prolonged periods of time.

ALWAYS FOLLOW THE CLEANING INSTRUCTIONS

- Wipe with a clean colourfast cloth dampened with mild alkaline free soap and luke warm water. Do not wet excessively.
- Remove all traces of any cleaning product by wiping with fresh water and a clean cloth.
- Dry with a soft, clean cloth.
- Stubborn grime may require gentle scrubbing with a soft brush.

Do not use:

- · hot or boiling water
- hydrocarbons including alcohol
- acetone
- furniture polishes
- bleach
- concentrated detergents
- abrasive powder or paste cleaners
- steel wool
- silicon or petroleum-based cleaners
- · solvent based or abrasive cleaning agents

MAINTENANCE

A periodic inspection of all components and fasteners should be made to ensure that your Comfortel Product is structurally intact and functioning properly.

Damaged and broken parts should be replaced and loose fasteners tightened.

All maintenance to be carried out by a suitably qualified tradesperson.

HOW TO CHANGE A SHOWERHEAD OR SHOWERHOSE

Please view our online how to videos and further troubleshooting: https://help.comfortel.com.au/hairdressing-basins/

comfortel

help.comfortel.com.au

The information contained in this document is subject to change without notice and should not be construed as a commitment by Comfortel Furniture Pty Ltd.

Comfortel Furniture Pty Ltd. assumes no responsibility for any errors that may appear in this document nor does it make expressed or implied warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Comfortel Furniture Pty Ltd. shall not be liable for incidental or consequential damages in connection with or arising out of the use of this document and the program material.

PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE

For more information about our products and services, contact us at comfortel.com.au

WARRANTY PERIOD

Revision Date: 22.07.2021

of Comfortel Furniture Pty Ltd.

©Comfortel Furniture. All rights are reserved. No part of this document may be photocopied, reproduced or

translated to another language without written consent

TERMS AND CONDITIONS. For more information about our warranty, please refer to our website

PURCHASE DATE

INVOICE NUMBER

NOTE YOUR PURCHASE DATE & INVOICE NUMBER FOR FUTURE REFERENCE