User Guide for TESLA Instrument Panel

This product specially designed for Tesla Model-3 & Model-Y with original style and original UI, convenient the driver head up to view the vehicle driving information while driving, avoid potential safety hazards caused by viewing large screens with a slanted head.

Perfect connect iOS & Android smartphones with CarPlay and Android Auto, use the smartphone apps.

The easy and simple system setting can help you easy get through all functions of the device, the firmware upgrade service will upgrade device with latest firmware will get better experience, and you can choose different UI for fun drive.

Contant

Navigation Bar

Slide left from the right edge of the screen to pop up the navigation bar. Click the function icon to jump to the corresponding interface

Instrument Panel

Smartphone Connect

System Settings

Rolling the right wheel of the car's steering wheel can also trigger the switching effect. Note: If there is no operation within 5 Seconds, the navigation bar will automatically hidden.

Instrument Panel Info Display

Main Display Area

Brightness Bar

Vehicle Status

Speed

Turn Signal Light

Speed Limit Mark

Driving State

190

MPH

P   R   **N**   D

20℃   216mi/0mi

100%   15:20

Outdoor Temperature

Total Kilometers

Volume Bar

Energy State   Gear   Battery Capacity   Time

In the main display area, you can switch the display content by sliding left or right: parking status (front trunk & rear trunk & doors, when the above status is abnormal, the parking status will be actively popped up), tire pressure info, and driving status.

Day Mood (Instrument Panel will switch to day mood with the Central Display automatically)

Night Mood (Instrument Panel will switch to night mood with the Central Display automatically)

Slide up and down on the left side of the instrument panel to manually adjust the instrument panel speaker volume.

Slide up and down on the right side of the instrument panel to manually adjust the instrument panel LCD brightness.


Smartphone Connection Settings

The Smartphone Connection function support full screen display and split screen display. The default setting is split screen with left side display smartphone screen, and right side display part of the instrument information.

Click the Smartphone Connect Icon on the navigation bar

The Instrument Panel wil display the information: please open your smartphone Bluetooth connect the BT ID: BT-PLINK-XXXX.

CarPlay Connection

Open the System Setting Menu, find the Smartphone connection, choose the connection mood with CarPlay

Then use the iOS Smartphone use BT pairing search the BT ID: BT-PLINK-XXXX, and paring the device.

Confirm the paring code on smartphone and allow contacts, click allow to use CarPlay.

After seconds the CarPlay Interface will automatically display on the instrument panel.

| Bluetooth | |

This iPhone is discoverable as "恒哥^_^iPhone" while Bluetooth Settings is open.

MY DEVICES

BT-868	Not Connected ⓘ
BT-868	Not Connected ⓘ
dostyle SD802	Not Connected ⓘ
HAVAL	Not Connected ⓘ
MD158	Not Connected ⓘ
QiaoQiao-K	Not Connected ⓘ
ZORDAI	Not Connected ⓘ

OTHER DEVICES

| BT-PLINK-2238 |

To pair an Apple Watch with your iPhone, go to the Apple Watch app.

Bluetooth ⬤

This iPhone is discoverable as "恒哥^_^iPhone" while Bluetooth Settings is open.

MY DEVICES

BT-868   Not Connected ⓘ

BT-8   ⓘ

dos   ⓘ

HA\   ⓘ

MD   ⓘ

Qia   ⓘ

ZORDA   Not Connected ⓘ

Bluetooth Pairing Request

"BT-PLINK-2238" would like to pair with your iPhone. Confirm that this code is shown on "BT-PLINK-2238". Do not enter this code on any accessory.

565997

Cancel   Pair

OTHER DEVICES ⟳

BT-PLINK-2238   ⟳

OGA191119642

To pair an Apple Watch with your iPhone, go to the Apple Watch app.

Bluetooth ⬤

This iPhone is discoverable as "恒哥^_^iPhone" while Bluetooth Settings is open.

MY DEVICES

BT-868   Not Connected ⓘ

BT-868   Not Connected ⓘ

dos   ⓘ

HA\   ⓘ

MD   ⓘ

Qiao   ⓘ

ZORDAI   Not Connected ⓘ

Allow Contacts and Favorites Sync?

Your car may request your contacts, phone favorites, and recent phone calls over Bluetooth. Do you wish to allow this? CarPlay will work without syncing.

Don't Allow	Allow

OTHER DEVICES

BT-PLINK-2238

OGA191119642

To pair an Apple Watch with your iPhone, go to the Apple Watch app.

Settings

|		
✈	Airplane Mode	⬜
🛜	WLAN	HUAWEI-B91CW8 ›
✳	Bluetooth	On ›
📶	Cellular	›
🔗	Personal Hotspot	Off ›

Use CarPlay with "My-CarPlay"?

CarPlay automatically connects your iPhone to your car's built-in display, and can access your phone while it is locked.

Not Now	Use CarPlay

|		
⚙	General	›
🎛	Control Center	›
AA	Display & Brightness	›
📱	Home Screen	›
♿	Accessibility	›
🌸	Wallpaper	›

Android Auto Connection

Open the System Setting Menu, find the Smartphone connection, choose the connection mood with A-Auto.

Open the Wi-Fi Setting, and share the Smartphone's hotspot with the Instrument Panel. For better experience please choose the Smartphone hotspot with 5G transmit band.

Open the Android Phone BT pairing function, search BT ID: BT-PLINK-XXXX, and paring the device. After around 10 seconds, the AndroidAuto interface will display on Instrument Panel.

And you can also use the Type-C Cable connect the Android Smartphone into the Type-C port on the Instrument Panel with wired Android Auto function.

Note：

Before using the smartphone connection, please check the System Settings, if the Connection mood is CarPlay or Android Auto, if choose wrong mood, the smartphone will unable to connect with the instrument panel.

The default setting is CarPlay Mood.

After switching the right mood, the Instrument Panel will automatically restart, make the settings work.

Note:

CarPlay and Android Auto support Full Screen and Split Screen mood.

System Settings Interface

Choose the System Settings Icon on the Navigation bar, will enter the system setting information. You can choose System Language, Smartphone connect mood, display mood, car color, time, steer wheel control, temperature unit, brightness adjust mood, Wi-Fi function, system information, software update, UI Style switch.

About System Update

We will bring better user experience with our firmware up to date service.
The device connect to Wi-Fi, choose check update, if there is new firmware the system will update automatically, and system will reboot.
Please do not power off.

About the UI Switch
In system upgrade menu, there is a theme upgrade sub menu.
You can freely switch different UI which you like.
After switching the device will automatically reboot.

Steer Wheel Control functions

Steer Wheel Control functions	
1. Left Push: Play Pervious Song/Hang off Phone Call	4. Left short push: Back to pervious menu Left long push: back to Instrument Panel
2. Short Press: Play/Pause Music Long Press: Active Smartphone Voice	5. Up/down rolling: switch between Instrument panel and smartphone

Assistant	connection interface
3. Right Push: Play Next Song/Pick up phone Call	6. Right short push: Enter Smartphone Connection interface (CarPlay/Android Auto) Right long push: Enter Smartphone Steer Wheel control, short push is confirm function.

Note: Smartphone Steer wheel control function just work in Non automatic driving mode.