

PEAK

FORGEGRIP

BATTERY-POWERED CARTRIDGE GRIP MANUAL



GET A GRIP ON
WIRELESS POWER



- 1 WHAT'S IN THE BOX
- 2 PEAK FORGE WIRELESS GRIP DIAGRAM
- 3 GETTING STARTED WITH THE FORGE WIRELESS GRIP
- 4 TECHNICAL SPECIFICATIONS
- 5 KEY FEATURES




- ◆ **Collet Vice System:** This system includes a collet and nut
- ◆ **(1) RCA Cord**
- ◆ **(1) 3.5mm Cord**
- ◆ **(3) Drive Bars:** Each Forge Wireless Grip comes with an 85mm, 95mm, and 100mm drive bar to accommodate the geometry of your machine; choose the length that is most appropriate for your rotary machine when tattooing with the Forge Grip

COLLET VICE SYSTEM



DRIVE BARS




RCA CORD



3.5 MM CORD




MAGNETIC ATTACHMENT FOR
RCA OR 3.5MM INPUT CORDS



POWER BUTTON
(ALSO USED TO ADJUST VOLTAGE)

VOLTAGE LIGHT INDICATORS

GRIP SHAFT
(INSERT DRIVE BARS HERE)



USING YOUR PEAK FORGE BATTERY PACK

- 1 For universal needle machines that accept bar and cartridge needles, start by installing one of the included drive bars onto your machine. For dedicated cartridge needle machines, skip to step 2 to get started.
- 2 Insert the Forge Wireless Grip into the vice of your rotary machine and tighten the vice screw until the grip is locked in place.
- 3 Use the RCA cord or 3.5mm jacket cord depending on your tattoo machine's input connector. Attach the magnetic end of the cord to your Forge Wireless Grip and insert the RCA or 3.5mm input connector into your machine.
- 4 Insert your preferred cartridge needle before tattooing. The Forge Wireless Grip is compatible with all universal cartridge needles on the market.
- 5 To start or pause your Forge Grip battery, press the power button. Short press the power button again whenever you want to adjust your voltage between 6v and 11v. The red light will indicate which voltage you have selected.
- 6 When you're ready to recharge, connect your Forge Grip to a USB-C charging cable.



TECHNICAL SPECIFICATIONS

- ◆ **Net Weight:** 92g
- ◆ **Grip Body:** Constructed from durable aluminum
- ◆ **Battery:** Battery pack is USB-C chargeable; offers 6+ hours of tattooing power; battery capacity is 1400mAh
- ◆ **Voltage Range:** 6v-11v
- ◆ **Jumpstart Voltage:** 9v in 0.3 seconds
- ◆ **Package Includes:** Collet Vice System with collet and nut, RCA cord, 3.5mm cord, and 3 drive bars (85mm, 95mm, and 100mm)

KEY FEATURES

- ◆ Compact, lightweight cartridge grip
- ◆ Battery-powered (functions as a grip + wireless battery pack all in one)
- ◆ Forward weighted for optimal balance
- ◆ Charges quickly with USB-C cord
- ◆ Make easy voltage adjustments with one button
- ◆ Red light indicator shows your voltage
- ◆ Easy to wrap and break down for cleaning and autoclaving
- ◆ Compatible with rotary machines that have RCA or 3.5mm inputs
- ◆ Comes in Black, Pink, and Red color options



WARRANTY INFORMATION

We offer a one-year warranty on all our machines and technology. If you experience any technical issues with your Forge Wireless Grip, simply download and fill out the **Peak Repair Order Form**.



Mail your completed repair order form, your machine, and invoice as proof of purchase to the listed address.

If you purchased your Forge Wireless Grip less than a year ago, we will replace it with a brand new model. If your machine is older than a year, it is unfortunately no longer protected under our one-year warranty.

Any other questions or concerns regarding technical issues with your Forge Wireless Grip can be directed to info@peakneedles.com.

