Tupperware® BreadSmart / Large BreadSmart

Thank you for purchasing your Tupperware® BreadSmart container.

BreadSmart is an innovative storage solution from Tupperware® to keep bread fresher for longer. It is suitable for storing many different types of bakery items including croissants, baguettes, pastries and more.

The BreadSmart container uses CondensControl™ technology to create the perfect environment right inside the box. BreadSmart works by allowing excess humidity to be released through the CondensControl™ membrane reducing the potential for mould growth, and cleverly it also prevents your bread from drying out.

How to use your BreadSmart container:


- After purchasing your bread or bakery items <u>remove all packaging</u>, place inside the container and place the lid on to the base.
- Note: The BreadSmart Lid is NOT designed to seal on to the base. This is so that the CondensControl[™] technology will get to work, creating the perfect environment to keep your bread fresher for longer.
- Some loaves are quite tall but don't worry you can still store the loaf in your BreadSmart container, just place the loaf in the container on its side.
- · Performance will vary subject to the freshness and type of bread.
- When removing your bread or bakery products from the BreadSmart container, replace the lid immediately.
- Removing the lid for long periods of time or repeatedly removing and replacing the lid will reduce the effectiveness of your BreadSmart container.
- BreadSmart should be kept in your pantry or inside a cupboard. <u>Do not store in the fridge.</u> Store in a cool dry place and keep out of direct sunlight.

How to care for your BreadSmart container:

- · Hand wash before first use.
- BreadSmart should be washed by hand using a soft cloth. Do not use abrasive cleaning products.
- Always wash and thoroughly dry the BreadSmart container after each use. Any moisture could affect performance.


Tupperware® BreadSmart

- Parts included: Base, lid & divider.
- The divider in your Breadsmart is suitable for separating two different items and is perfect for keeping your sliced bread together.



Tupperware® Large BreadSmart


- Parts included: Base, rim, lid & black rubber feet.
- Do not use the lid as a chopping board. The black rubber feet should be inserted into the base of the lid to protect your surfaces.




WARNING: Please do not remove, damage, or perforate the CondensControl™ membrane in the rim/lid as this will affect performance.



Tupperware® BreadSmart / Large BreadSmart





Specially designed for food

Handwash only

Not suitable for freezing

Not suitable for microwave Not suitable for oven

Not suitable for grill

Do not use knives or sharp objects















United Kingdom & Ireland

Distributed by High Street TV, PO Box 7903, Corby, NN17 9HY

Need Help? We're here for you.

Please contact our Customer Services Team on: Phone: 0344 800 0491 Email: hello@tupperwaredirect.co.uk

For instruction videos and FAQ's visit tupperwaredirect.co.uk



Tupperware® products are legendary for their longevity, but things do happen, so we're proud to back up our already durable products with an extensive warranty and 10 year guarantee. Tupperware® brand products are warranted by Tupperware against chipping, cracking, breaking or peeling under normal non-commercial use for 10 years. For full details of the warranty and to register your product, please see tupperwaredirect.co.uk/warranty.



