





Maintenance Instructions

Rollators and Walkers



Images show a selection of rollators and walkers

Important advisory!



Maintenance of the rollator and walker

1.1 Maintenance / inspection requirements

In this maintenance instructions pamphlet you'll find information and advisories on the safe and professional maintenance and/or repair work on rollator and walker.

The products are Class I medical products as to the 93/42/EEC and the German MPG/Medical Products Act.

As to the requirements of the German **MPBetreibV** Medical Products Ordinance, the products must be maintained and the hygiene requirements must be adhered to. Check your local requirements.

The product's lifetime is in large part affected by how it is used. The frequency of use and manner of use reduces the lifetime as does improper handling and inadequate maintenance.

In order to ensure safe use, a visual inspection and function check must be done at least once per year. Shorter time intervals between maintenance may be necessary when the frequency of use or the condition of the product exists due to safety reasons.

The operator has to carry out the maintenance on his own or must instruct a competent person (specialized supplier, medical supply store or a medical-maintenance-service) if he has not the needed expertise.

Inspection results must be documented and be confirmed by a signature. The product it is recommended with an inspection sticker that states the next inspection. The product operator is responsible for assuring regularly-conducted inspections.

1.2 Maintenance scope

The product's inspection extends from the general condition to the individual components, function and safety.



Necessary repair wroks must be done without delay. If an immediate repair work is not possible, then it is in the patient's interest and health to put the product out of service.

1.3 Maintenance advisories

When making repairs, use only original spare parts from REBOTEC.

Do not undertake any modifications or conversions to the product on your own. These will adversely impact the product's safety and function. REBOTEC accepts no liability in such cases.

When performing maintenance and repairs, please use the product's User Instructions booklet as an aid and follow the instructions concerning proper use, re-use, lifetime, guarantee, care and maintenance.

After completing maintenance or repair work on the product, follow the requirements for hygiene for re-use.

1.4 Maintenance reports and overview

In the appendix you will find a form for documenting maintenance. You can make copies of the form. This allows you to keep an overview of the product's maintenance status.



Maintenance protocol (single report)
It is a form for proof of a single maintenance session.

Maintenance overview (total report)
It is a form for proof of executed maintenance sessions.

1.5 Disposal

For disposing of the product, follow all the advisories in the product's User Instructions booklet. Disposal must be done at a recycling company. Contact your local recycling company for more information.

1.6 Transport and storage

For transporting or storing the product follow the instructions of the particular user manual.

| Prod | 40t ::::0:::uc::0:: / :: | | | : I) | REBB02.11. | 1/0-17-0 | | |
|-------------------|--------------------------|--|----------------|----------------------|------------|----------|--|--|
| Car: | | collator, Walker (medical p | noudot olass | , , , | KEBB02.11. | .145-17- | | |
| Seri | al no. | Year of | Use | | | | | |
| Man | ufacturer | | • | | | | | |
| Use | | | | | | | | |
| Loc | ation of | | | | | | | |
| | tenance- Genera | | | | | | | |
| Р | Checks | Scope of work | k | Remarks | Fine | ding* | | |
| 1. | Visual inspection | General damage, wear an | d corrosion | corrosion | | | | |
| 2. | Connection elements | Completeness, seat, funct (screws, nuts, etc.) | | | | | | |
| | | Folding mechanism | | | | | | |
| 3. | Functions | Height adjustment | | | | | | |
| | | Brake (permanent lock/no | rmal brake) | | | | | |
| 1-:- | | mant abaaldaa | | | • | | | |
| <u>viain</u> P | tenance- Compo | Scope of work | | Remarks | Fin | nding | | |
| 1. | rollator frame | Damages | | Remarks | | .ug | | |
| 2. | grip bow | Function, fastening | | | | | | |
| 3. | swivel castors | Function, damage, wea | ır | | | | | |
| 4. | brake wheels | Function, damage, wea | | | | | | |
| 5. | brake levers | Function, damage, wea | | | | | | |
| 6. | hand switch | Function, damage, wea | | | | | | |
| 7. | wood seat | Stability, damage, wear | | | | | | |
| 8. | cushion | Damage | | | | | | |
| 9. | accessory | Function, wear | | | | | | |
| 10. | YANO-support | Function, fastening | _ | | | | | |
| 11. | YANO-handle | Function, damage, wea | ır İ | | | | | |
| 12. | Castor brakes | Function, damage, wea | | | | | | |
| 13. | YANO-accessory | | | | | | | |
| | _ | =exchanged' R=repaired, i.o | | i.o. = not in order | | | | |
| | following parts w | vere replaced: (Use only | original parts | from the manufacture | er) | | | |
| | Qty. Article description | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| Qty. | | | November | | | | | |
| Qty. | tenance results | | | naintenance: | | 1 | | |
| Qty. | ual check i.O. | n.i.O Function chec | ck i.O. | n.i.O Passed | + = ' = | no | | |
| Qty. | | n.i.O Function chec | ck i.O. | | d yes _ |] no | | |
| Qty. | ual check i.O. | n.i.O Function chec | ck i.O. | n.i.O Passed | + = ' = | | | |
| Qty. | ual check i.O. | n.i.O Function chec | ck i.O. | n.i.O Passed | + = ' = | | | |

Maintenance overview



Product information / Rollator, Walker (medical product class I)

| Product | , | , | |
|-------------------------|---------------------|----------|-----------|
| Serial no. | Year mai | nuf. Us | se start |
| Manufacturer | | | - |
| User | | | |
| Location of use | Inventor | y no. | |
| | | <u>.</u> | |
| 1st Maintenance Date | Maintenance company | Report | Signature |
| | | | |
| Remarks: | | | |
| | | | |
| | | | |
| 2nd Maintenance Date | Maintenance company | Report | Signature |
| | | | |
| | | | |
| | | | |
| Remarks: | | | |
| | | | |
| | | | |
| 01.1.1 | | T | |
| 3rd Maintenance Date | Maintenance company | Report | Signature |
| Date | | | |
| | | | |
| | | | |
| Remarks: | | | |
| | | | |
| | | | |
| | | | |
| 4th Maintenance Date | Maintenance company | Report | Signature |
| | | | |
| | | | |
| | | | |
| | | | |
| Remarks: | | | |

| 5th Maintenance Date | Maintenance company | Report | Signature |
|-------------------------|---------------------|--------|-----------|
| | | | |
| | | | |
| | | | |
| Remarks: | | | |