


To cover all your training needs, ArcX has five modes



Playlist mode

ArcX works with all major music apps including Spotify, Apple Music, Audible, Soundcloud and YouTube.

Camera mode

Use ArcX to control sports cameras and smart phones to capture selfies, group photos and action shots.

Stopwatch mode

Use ArcX to take your split and lap times. You can still listen to and control music when the stopwatch function is active.

Call modes

The SOS call function can be triggered from any mode by pressing and holding the centre button for five seconds. This calls the emergency services number in your region and also sends an SMS requesting help along with a Google map link of your current location.

Everything else mode

Use ArcX as a remote control for your phone to take selfies and TikTok videos or use it to control sports cameras, wireless speakers, e-skateboards, AR/VR glasses, laptops, desktops, TVs and any other Bluetooth enabled gadget or device.