


LOCK INSTRUCTIONS

The lock is pre set to 0-0-0

1. Push the button 1 in the direction of the arrow
2. While in this position set each number to your selection
3. Release the button and your number is now set
4. Take care when setting the numbers not to release the button



LOCK INSTRUCTIONS

The original number is 0-0-0,

To set your own password :

1. Put the dials (B) at its original numbers 0-0-0.
2. Press down the reset button (C) with a tool until hear the "click" sound.
3. Set your own password by turning the dials(B), for example 8-8-8.
4. Push the button(A) towards the direction of arrow, The reset button (C) will be back when you hear the "click" sound.

Now you have finished setting your own password,

Please remember your password by heart.

Please repeat the above steps to reset the numbers.

The suitcase can be locked with any combination.

It can be open only with your combination.

Please keep your combination safe - if you forget it, there is no way to open your lock!

