

## Products Warranty - Australia

For warranty details see our website:

<https://www.faucetstrommen.com.au/warranty/>

# Installation Guide **IG 002**

Release Date: 13.12.22

## Sleeve Mount Sink & Basin Mixers



### Suits Models:

30560, 30561, 30562, 30563, 30564, 30565, 30566, 30568, 30569, 30634, 30635, 30636, 30637, 30638, 30639, 30640, 30690, 30691, 30692, 30693, 30696, 30697, 30698, 35100, 35101, 35102, 35126, 35127, 35128, 35130, 35131, 35133, 35137, 35139

### Important requirements:



Must be fitted in accordance with AS/NZS 3500 by qualified plumber



Mains 500kpa regulator must be fitted



Maximum hot water temp. 65°C



Mini stop taps must be fitted



Water lines must be flushed prior to connection



Only clean municipal water supply. No bore, dam or hard water without filtration & treatment

### Cleaning

Clean only with a soft microfiber or similar cloth and warm clean water. Ensure that the cloth is clean and free of any grit or chemical. Dry tap off with a soft clean cloth. Ensure that your tap is not subject to any chemicals, building grit or any type of abrasive or polish. For care of special finishes please visit our website.

### Maintenance

Aerators may need to be flushed from time to time if flow diminishes or stream pattern deteriorates. For Pegasi & Cascade mixers, use the aerator key provided to unscrew the aerator. You will notice a "castle" pattern around the edge of the aerator, the key engages with this allowing you to unscrew the insert easily. For Zeos models, use the aerator key to unscrew the aerator housing, you will then be able to pop the insert out the top of the housing. Rinse off the upper face of the insert with running water and gently brush clean with an old toothbrush to remove any debris before refitting the aerator.

### Rough in:

1. Carefully remove the mixer from the box and screw the threaded mount sleeve into the base of the mixer, firmly hand tighten only.
2. Press the large O-ring into the base of the dress ring and slide the dress ring over the mount sleeve to locate into base of mixer.
3. Thread the 2 flexi hoses into the base of the mixer. The blue braided hose connects to the port marked "C" and the red hose to the "H" port. Thread the hoses in hand tight only.
4. Bring the tap into position, press the flexible hose nuts through the tap hole and insert the mixer into the hole (if the hole is deep and does not permit both nuts to go through you can remove one hose and fit it once the tap is mounted)
5. Insert the three Phillips head screws into one side of the brass mount nut (not to protrude through the other side) and locate the stainless horseshoe washer over the nut.
6. Slide the black rubber washer over the hoses and mount sleeve under the bench/sink then screw the mount nut onto the mount sleeve with the stainless washer to the top.
7. Position the tap then hand tighten the brass mount nut.
8. Fasten the tap in place with the 3 Philips screws. Not a lot of force is required to secure the mixer firmly. Do not overtighten.
9. Flush the water supply lines by running water through the mini supply stop taps into a bucket.
10. Connect the hoses to the water supply mini stop taps, Blue braid to the cold supply and red braid to the hot supply. Nip up very gently with a spanner. Do not overtighten.
11. Open the handle of the mixer then slowly open the supply stop taps. Once the air has exited the tap you can close the tap handle.
12. Run and operate the tap, check for any leaks or issues. If you have any concerns contact Faucet Strommen before leaving the site.

