






## PANEL INSTRUCTIONS



## SETUP INSTRUCTIONS

### 1. Single shot grinding time

Long press  into the setting mode, press  again to reduce 0.1 second, press  to increase 0.1 second. After setting the time and press  to confirm, then return to the single shot mode.

### 2. Double shot grinding time

The setting mode is the same as above.

## EXCEPTIONS

Product failure or damage under one of the following circumstances is not within the scope of warranty.

1. Product failure caused by using accessories other than our company;
2. Product failure caused by unauthorized disassembly of the machine;
3. Product failure caused by failure to operate in accordance with the instructions;
4. Obtain this product through illegal means or channels;
5. Product failure caused by force majeure;
6. Products repaired by unauthorized third-party personnel without contacting the company and its authorized dealers.

## WARRANTY AND AFTER-SALES SERVICE

The warranty period is one year from the date of receiving the product. Under the warranty conditions and period, the company will provide all-round warranty services according to the regulations if the product has problems such as failure and abnormality:

1. Repair the faulty machine free of charge espresso
2. Free replacement of faulty accessories (except burr)
3. Projects stipulated by laws of other countries


## APPLICATION AND USAGE

This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments.

Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.

# DF64E ESPRESSO COFFEE GRINDER INSTRUCTIONS



Please read this manual and keep it properly before using the product



# SAFETY PRECAUTIONS

- \* It is forbidden to modify this product without authorization;
- \* Do not place this product near the fire source;
- \* It is forbidden to wash the outside and inside of the product with water;
- \* Do not use this product outdoors or in direct sunlight;
- \* Do not grind crops other than coffee beans;
- \* Do not let children operate, touch or climb this product;
- \* Do not squeeze, pull, knot or damage the power cord;
- \* If the power cord is damaged, it must be replaced by the manufacturer or professional after-sales maintenance service personnel in order to avoid the risk of electric shock.

# PRODUCT PARAMETERS

Name	Coffee Grinder
Model	DF64E
Product size	L19 * W12 * H42cm
Carton size	L36 * W17 * H36cm
Net weight	6.7kg
Gross weight	7.8kg
Rated voltage	200-240V/50Hz
Rated power	250W
Burr	64mm flat
Grinder capacity	225g
Bellows capacity	50g

# PRODUCT INTRODUCTION

## 1. Hopper lid

ABS

## 2. Hopper

Food grade SAN,  
Capacity: 225g

## 3. Upper burr carrier

Aluminium alloy

## 4. Decorative cover

Black walnut

## 5. Control panel

Electronic control, three operation modes

## 6. Holder


Aluminum alloy, frosted and painted

## 7. Grinding adjustment lever

Stepless adjustment, accurate adjustment and labor-saving design

## 9. Base

Aluminum alloy and spray painting



## 8. Body

Aluminum alloy and spray painting


## 10. Switch

Metal texture with power indicator

# ACCESSORIES


## 1.Dosing cup

Food grade materials SAN, transparent design to see the condition of the internal coffee powder.



## 2.Bellows


Capacity of 50g, with lid be used to clean the inside coffee powder to make no retention.



# GRINDING ADJUSTMENT

The grinder adopts stepless adjustment design, which can easily and labor-saving adjust the grinding thickness of coffee.

**Note:**  
Please adjust the thickness when there are no coffee beans in the grinder, or when the grinder motor is running.



# OPERATING INSTRUCTIONS

- STEP 1**  
Put the coffee beans into the hopper and open the hopper door;
- STEP 2**  
The control panel will light up after press the power button. Touch either of single shot/ double shot / manual control mode to start the grinding function;
- STEP 3**  
After grinding, press the power switch to turn off the machine.

# CLEANING PROCESS

- Step 1.** Install the bellows on the upper burr holder, press the power switch to start the motor, then press the bellows by hand to blow out the residual powder inside the grinder;
- Step 2.** Turn off the switch, unplug the power cord and remove the screws with a hexagonal wrench;
- Step 3.** Take out the upper burr holder and clean up the residual coffee powder on the burr with a dry brush;
- Step 4.** Clean the powder outlet with a dry brush;
- Step 5.** Install the upper burr holder back, lock the screws.

