

Pangea Table Lamp Tall - 272120

Component Parts

A Lamp

B Turn Knob

C Harp Holder

D Socket

E Harp

F Harp Locks (2)

G Finial

H Shade

I Bulb (not included)


Pangea Table Lamp Tall - 272120

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJU-RY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Install Shade (Figure 1)

- 1. Carefully unpack fixture (A) from carton.
- Install turn knob (B) onto socket (D).
- Finial (G) is shipped installed on harp (E).
 Remove finial (G) from harp (E) and save for later use.
- 4. Install bulb (I) (not included) into socket (D).
- 5. Squeeze harp (E) together while holding the locks (F) up towards the top of the harp and slip into harp holder (C).
- 6. Allow locks (F) to slip down harp (E) and onto harp holder (C) to secure harp in place.
- 7. Set shade (H) onto threaded stud on top of harp (E).
- 8. Thread finial (G) onto threaded stud on harp (E) and tighten until snug. Be careful not to over tighten.
- 9. Plug in power cord.



If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!

* Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.

