

LED Floor Lamp

FL25558
INSTALLATION SHEET

START FROM HERE


- Prepare everything in a clear area
- Wear gloves at all time during this installation
- Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

Please Note:

- This Kuzco LED fixture come with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- Touch Dimmer
- 120V input

- 1.** Remove fixture from its original package.
- 2.** Plug lamp head (**1a**) into socket (**1b**), lock with set screw using Allen key (**2b**).
- 3.** Connect mating connectors (**1e**) before inserting upper section (**1c**) into base (**1h**), lock with screws using Allen key (**1g**) and then close with magnetic cover (**1f**).
- 4.** Plug driver (**3e**) into outlet.
- 5.** Turn on/off/select brightness at switch (indicated by hand icon)



KUZCO

19054 28th Avenue Surrey, BC Canada V3Z 6M3
T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196
W: kuzcolighting.com
20211222