

## **HEATED VEST**



## **User Manual**

For any questions or concerns, please contact us at support@neberon.com


# IMPORTANT SAFETY WARNINGS AND INSTRUCTIONS

Read all safety warnings and instructions before using the product. Failure to follow these may result in electric shock, fire, and/or serious injury. Save these warnings and instructions for future reference.


- This heated vest is designed for keeping a person warm in cold environments.
  Do not use it in any other way.
- 2. Not recommended for infants, children, or people with health issues.
- The vest is not to be used by a person with poor blood circulation unless he/ she is carefully attended to.
- 4. Do not use this vest on the skin that is insensitive to heat.
- 5. Do not use the power cord as a handle.
- 6. Never use the vest if the cord shows any sign of damage.
- 7. Only use the original power bank provided by us.
- 8. Do not attempt to disassemble or alter any part of the vest.
- 9. Do not expose the vest to high temperatures.
- 10. NEVER wear the vest if the inner liner is wet. Once the vest is wet by rain or splashes, shut off the power and stop using it immediately.
- 11. Do not wear the vest over bare skin.


- Shut off the power and unplug the cable immediately if any discomfort occurs.
- 13. Do not use pins or badges on the vest, as this may cause damage to the electric wiring inside the vest.
- 14. Do not pinch the power cords.
- 15. Do not wring out the vest as this may cause damage to the heating elements or wire hardness.

## WHAT'S INCLUDED



## **PRODUCT OVERVIEW**






- 1 Inner Pocket
- 2 Front Heating Zones
- 3 Right Pocket
- 4 Front Power Button
- 5 Back Power Button

- 6 Left Pocket
- 7 Battery Holder Pocket
- 8 Power Cable
- 9 Back Heating Zones

## **OPERATION GUIDE**

## 1. Charge

Before the first-time use, please fully charge the power bank with the power adapter we provided. It takes about 5 hours to reach a full charge.



#### **Battery Status Indicators**


Battery Power	Indicators
≤25%	
25%-50%	• 0 0 0
50%-75%	• • 5 5
75%-100%	• • • 0
Full	• • • •

#### Tips:

- 1. O Solid On
  - Flashing, indicating the power bank is getting charged.
- 2. When the power bank is not getting charged, you can press the battery check button to check the remaining battery power.


## 2. Plug-in

Unzip the left pocket and find the battery holder pocket. Take out the power cable and plug it into the power bank. Then, put the power bank into the battery holder pocket.




#### 3. Turn On

To turn on the vest, press and hold the front power button and/or the back power button for 2 seconds until the LED indicator(s) turn(s) red.



## 4. Adjust Heating Levels

Shortly press the power button to adjust the heating levels.



Heating Level	Temperature	Heating Duration (Turn on Both the Front and Back Heating Zones)
High(Red, Default Setting)	131°F(55°C)	3 Hours
Medium(White)	122°F(50°C)	About 4 Hours
Low(Blue)	100°F(38°C)	About 8 Hours

Heating Level	Temperature	Heating Duration (Only Turn on the Back Heating Zones)
High(Red, Default Setting)	131°F(55°C)	About 4 Hours
Medium(White)	122°F(50°C)	About 6 Hours
Low(Blue)	100°F(38°C)	About 10.5 Hours

Heating Level	Temperature	Heating Duration (Only Turn on the Front Heating Zones)
High(Red, Default Setting)	122°F(50°C)	About 9 Hours
Medium(White)	113°F(45°C)	About 12.5 Hours
Low(Blue)	100°F(38°C)	About 20.5 Hours


<sup>\*</sup> The data is tested from the neberon lab.

#### Tip:

To minimize distraction, the power button lights are programmed to turn off after 1 min (several quick blinks before off) and enter "sleep mode". In sleep mode, the heating mechanism is still working. The lights can be reactivated to show the current status by a single press of either "sleep" button, and you may continue pressing the button(s) to adjust heating power.


#### 5. Turn Off

To turn off the vest, press and hold the power button(s) for 2 seconds again or directly unplug the cable.



## POWER BANK INSTRUCTIONS

#### Overview



- 1 DC Output Port
- 2 Type-C Input Port
- 3 USB Output Port

- 4 Battery Status Indicators
- 5 Battery Check Button

## Specifications

Model	V-1000
Cell Capacity	9600mAh
Type-C Input	5V 2.4A Max
DC Output	7.4V === 2.5A Max (4250mAh/31.45Wh)
USB Output	5V === 2.4A Max (6100 mAh/30.25Wh)

## Warnings

- 1. Fully charge the power bank before your first-time use.
- 2. Do not charge the power bank when it is hot. Let it cool down first.
- 3. Do not charge the power bank next to flammable material or on electrically conductive surfaces
- 4. Do not attempt to disassemble or alter the structure of the power bank.
- 5. Do not strike the power bank and protect it from impact.
- 6. Do not dispose of the power bank in fire or any liquid.
- 7. Do not expose the power bank to high-temperature or low-pressure environments.
- 8. Only use the adapter provided by neberon to charge the power bank.
- When the power bank is not used frequently, please fully charge it every 6 months to extend its life span.
- Dispose of the power bank according to the local environmental regulations. Do not treat it as household waste.

#### WASHING INSTRUCTIONS

Before washing, please unplug the power cable and remove the power bank. After removing, please put the power cable back into the battery holder pocket, then zip the left pocket.



Machine Wash With Laundry Bag



entle Cycle in Cold Water



Hang Dry Recommended



Do Not Iron



Do Not Bleach



Do Not Dry Clean



Do Not Wring or Twist

## Tip:

After drying, please shake or pat the vest with your hands to make it fluffy.

## Q&A

#### Q1. If I ordered the wrong size, can I exchange it for a different size?

\* Yes, you can. Please follow the Amazon exchange & return policy or contact neberon customer service team for the exchange.

## Q2. Why does the LED indicator on the power button flash three times and then become off after 1 minute when I select a heating level?

\* To minimize distraction, the power button lights are programmed to turn off after 1 min (several quick blinks before off) and enter "sleep mode". In sleep mode, the heating mechanism is still working. The lights can be reactivated to show the current status by a single press of either "sleep" button, and you may continue pressing the button(s) to adjust heating power.

#### Q3. Can I only heat my belly or my back?

\* Yes, you can. The front power button controls the heating zones in the front of the vest, while the back power button controls the heating zone on the back of the vest. You can not only power on/off all the heating zones at the same time, but also power on/off the front heating zones and the back heating zone respectively as needed.

If you have any questions or need any help, please contact us at **support@neberon.com**.