













FOR SAFE RIDING PLEASE HEED THESE SAFETY PRECAUTIONS AND WARNINGS

-  THIS PRODUCT IS INTENDED FOR ADULT USE ONLY. JACKRABBIT IS FUN, BUT NOT A TOY. NEVER PERMIT CHILDREN UNDER THE AGE OF 18 TO OPERATE IT.
-  RIDING AROUND CARS, PEDESTRIANS, OTHER CYCLISTS OR POTENTIAL HAZARDS BEFORE YOU ARE ABLE TO SAFELY DO SO COULD RESULT IN SEVERE INJURY OR EVEN DEATH.
-  NEVER RIDE UNDER THE EFFECTS OF ALCOHOL OR DRUGS.
-  TO AVOID UNINTENTIONAL MOVEMENT PUT YOURSELF IN THE PROPER RIDING POSITION, SEATED ON YOUR JACKRABBIT BEFORE PUSHING THE THUMB THROTTLE.
-  STOPPING YOUR JACKRABBIT: RELEASE THUMB PRESSURE ON THE THROTTLE AND APPLY THE HAND BRAKE UNTIL YOU COME TO A COMPLETE STOP.
-  JACKRABBIT'S TOP SPEED IS LIMITED TO 20 mph. HOWEVER, IT IS POSSIBLE TO EXCEED THIS SPEED WHILE COASTING DOWNHILL. PLEASE EXERCISE CAUTION IN THESE SITUATIONS.
-  DO NOT EXCEED THE WEIGHT LIMIT OF 240 lbs (109 kg).
-  JACKRABBIT IS INTENDED FOR SINGLE RIDER USE ONLY.
-  ALWAYS WEAR PROTECTIVE HEADGEAR!
-  RIDING JACKRABBIT IN FOUL WEATHER CONDITIONS (RAIN, HAIL, SLEET, SNOW, ETC.) IS NOT RECOMMENDED
-  DO NOT RIDE AT NIGHT (IN THE DARK) WITHOUT ILLUMINATING FRONT AND REAR LIGHTS.
-  BATTERY, MOTOR, AND ELECTRICAL SYSTEMS WARNING: RISK OF FIRE AND ELECTRIC SHOCK – NO USER SERVICEABLE PARTS. FOR SERVICE: INFO@JACKRABBIT.BIKE



JACKRABBIT OWNER'S MANUAL

Contains important info about your JackRabbit

For instructional videos and answers to frequently asked questions, scan this QR code to visit the JackRabbit.bike support page at

<https://jackrabbit.bike/support>



©2022, JackRabbit Mobility, Inc. (Oct-2022)

Record your JackRabbit information here:

Key Code: _____ Separate keys & keep 1 safe as backup!

Serial Number: _____ Frame color: _____

Date of Purchase: _____ Location of Purchase: _____

JACKRABBIT BOX CONTENTS

1. JackRabbit micro ebike
2. 110 volt AC input battery charger
3. Charging adapter (only needed if charging battery outside of bike).

ASSEMBLY INSTRUCTIONS

Your JackRabbit is pre-assembled and requires a few steps to get it ready to ride.

1. Remove all contents from the carton (including battery charger). Cut any zip ties and remove packaging padding.
2. Push black rubber “+” button above front wheel. Rotate front wheel 180 degrees.
3. Insert the handlebars into the stem hole until the silver pin under the “+” button on the stem clicks in place.
4. Turn knob on handlebar clamp clockwise to tighten and then push clamp towards stem to lock in place.
5. Squeeze the brake lever to confirm that the brake pads contact the rotor.
6. Set seat height so feet are flat on the ground when seated. Tighten the seat post clamp the same way as handlebar clamp.
7. Fold down the footrests.
8. Check the tires’ air pressures. All tires lose air pressure over time. 40 psi is the minimum. Inflating to 65 psi (maximum) will result in lower rolling resistance and increased battery range.

FIRST RIDE GUIDANCE

(Learning to ride JackRabbit is easy.)

First: top up the battery by plugging charger into the JackRabbit underneath at the front and add air to the tires.

Start out using it like a child’s balance bike:

- Before riding, test out the brake.
- Simply push with your legs and glide.
- Ride with the balls--not heels or arches--of your feet on the footrests.
- You’ll be surprised how fast you can coast and glide on flat ground.
- Sit comfortably and try not to lean on the handlebars -just use them for steering.
- Use your legs as shock absorbers by pressing down through your feet and lifting your tush off the seat.

After you get a feel for the braking and handling characteristics:

- Push the grey button on the throttle control to turn on the power.
- With both hands on the handlebars lightly push your thumb down on the throttle. Just a little bit at first!
- Release your thumb anytime to coast.
- Not much throttle is needed. “Pulsing” and glide-coasting is the best way.
- You can quickly and easily put both feet on the ground at any time--something you can’t do on a bicycle or scooter.

HOT TIPS & TRICKS

Charge the battery in the JackRabbit by plugging the charger directly into the JackRabbit underneath it near the front.

The keys are for removing the battery, which is only necessary if you have an extra battery or are taking your JackRabbit on an airplane.

Separate the keys and store one in a safe place as a backup. Lost keys are not replaceable!

The adapter that comes with the charger is only needed for charging spare batteries.

To remove the battery for using a spare battery or when flying with JackRabbit: insert key underneath, turn 90 degrees, and then use two hands to gently pull the battery straight up.

To insert a spare battery, make sure a key is inserted underneath then use both hands to lower battery straight down. Jiggle a bit to insert until battery top is flat on top of JackRabbit. No pressure is needed! Do not use force! Once fully inserted, rotate & remove key.

To fit JackRabbit into a car trunk, rotate front wheel. Watch our videos to see how!

Try Walk Mode! Watch our videos to see how!

Buy cool accessories at www.jackrabbit.bike

Contact us anytime at info@jackrabbit.bike

Ride safe, be respectful of others around you when riding, and HAVE FUN!