


INSTALLATION INSTRUCTIONS OPTIONAL LOUVERS

INSTRUCTIONS MUST BE LEFT WITH THE OWNER FOR FUTURE REFERENCE AFTER INSTALLATION.

ATTENTION: If Applicable, remove protective film from louvers before installation.

1. Remove original top and bottom louver from fireplace. Grasp louver, lift upward and pull forward.
2. Install optional top and bottom louver into fireplace. Grasp louver, insert louver into fireplace and push downward.
3. Installation of optional louvers is completed.



MODEL	PART NUMBER	
	UPPER LOUVER	LOWER LOUVER
DVG22ABL	24472	24460
DVG22ABR	24473	24461
DVG22AHP	24474	24462
DVG22ASS	24475	24463
DVG22LBL	24464	24452
DVG22LBR	24465	24453
DVG22LHP	24466	24454
DVG22LSS	24467	24455
DVG22MBL	24468	24456
DVG22MBR	24469	24457
DVG22MHP	24470	24458
DVG22MSS	24471	24459
DVG33ABL	18550	18550
DVG33AHP	18552	18552
DVG33ASS	18553	18553
DVG33LBL	18566	18566
DVG33LHP	18568	18568
DVG33LSS	18569	18569
DVG33MBL	18582	18582
DVG33MHP	18584	18584
DVG33MSS	18585	18585

MODEL	PART NUMBER	
	UPPER LOUVER	LOWER LOUVER
DVG35ABL	18554	18554
DVG35AHP	18556	18556
DVG35ASS	18557	18557
DVG35LBL	18570	18570
DVG35LHP	18572	18572
DVG35LSS	18573	18573
DVG35MBL	18586	18586
DVG35MHP	18588	18588
DVG35MSS	18589	18589
DVL22BL	24059	24058
DVL22HP	24489	24491
DVL22SS	24490	24493
FPK22	24054	24053
FPK36	24051	24052
VPL24HP	25987	25987
VPL24SS	25995	25995

MODEL	PART NUMBER	
	UPPER LOUVER	LOWER LOUVER
DVG1ABL	18850	18502
DVG1AHP	18552	18504
DVG1MBL	18582	18534
DVG1MHP	18584	18536
DVL1BL	17169	17170
DVL1HP	17635	17636
DVG2ABL	18554	18506
DVG2AHP	18556	18508
DVG2MBL	18586	18538
DVG2MHP	18588	18540
DVL2BL	17127	17128
DVL2HP	17645	17646
FBG36ABL	18981	18979
FBG36AHP	18994	18992
FBG36MBL	18963	18961
FBG36MHP	18963	18961
DVL36HP	18935	18936
DVG3ABL	18558	18510
DVG3AHP	18560	18512
DVG3MBL	18590	18542
DVG3MHP	18592	18554
DVL3BL	17187	17188
DVL3HP	17655	17656
DVG4ABL	18562	18514
DVG4AHP	18564	18516
DVG4MBL	18594	18546
DVG4MHP	18596	18548