

Attic Furnace

Type B Gas Vent Manifold

| Installation Key | | | |
|------------------|---------------------|----|-------------------------|
| 1 | DuraCap | 14 | Increaser |
| 2 | Storm Collar | 15 | Draft Hood Connector |
| 3 | Roof Flashing | 16 | Square Firestop Support |
| 4 | High-Wind Cap | 17 | Oval Pipe |
| 5 | Round Pipe | 18 | Oval to Round Adapter |
| 6 | Elbow | 19 | Oval Tee |
| 7 | Tee | 20 | Oval Tee Cap |
| 8 | Tee Cap | 21 | Oval Tee Support |
| 9 | Increaser Tee | 22 | Oval Firestop Spacer |
| 10 | Female Flex Adapter | 23 | DuraConnect II |
| 11 | Male Adapter | 24 | DuraFlex AL Length |
| 12 | Double-Wall Wye | 25 | DuraFlex Motar Sleeve |
| 13 | Pipe Collar | 26 | DuraFlex AL Coupling |

Refer to our Typical Venting Installation drawings to select the appropriate component parts for your installation.

