

MBUDS 521 TWS Earbuds

User Manual







Charging:

Charge/Storage Case:

Connect the case to a charger using a Type-C charger to charge the Charge/Storage Case.



Earbuds:

Place the earbuds in the charged Charge/Storage Case to charge the earbuds.

Note: Please take off the sticker peels attached to the earbuds before you charge them.

To Connect:

Charge the Charge/Storage Case and the Earbuds at least 70% before the first usage.

Pairing:

- 1. Take out the Earbuds from the Charge/Storage Case and place them in your ears.
- 2. Go to the Bluetooth settings of your device and switch it on.
- 3. Scan available devices.
- 4. Connect 'Mobilla MBuds 521' to your device.

After completing the pairing process, the TWS earbuds will connect to your device automatically when you take them out of the charging/storage case.



Smart Touch:

Play/Pause:

Single tap on the Multi-Function Touch Area.

Repeat Track:

Long Press for 2 to 3 seconds on the Multi-Function Touch Area of the left earbud.

Next Track:

Long Press for 2 to 3 seconds on the Multi-Function Touch Area of the right earbud.

To Increase Volume:

Double tap on the Multi-Function Touch Area of the right earbud.

To Decrease Volume:

Double tap on the Multi-Function Touch Area of the left earbud.

Switch Between Gaming, Theatre & Bass Mode:

Triple tap on the Multi-Function Touch Area of the right earbud.

To Answer/Hang Up Calls:

Single tap on the Multi-Function Touch Area.

To Decline Calls:

Tap and hold on to the Multi-Function Touch Area.

Power On/Off:

Long press for 4 to 5 seconds on the Multi-Function Touch Area.

Call Voice Assistant:

Triple tap on the Multi-Function Touch Area of the left earbud.



Specifications:

- Bluetooth Version: 5.3
- Music Playtime: Up To 42 Hours
- Passive Noise Cancellation
- Sweat and Water Splash Resistant: IPX4 Rating
- ENC: Environmental Noise Cancellation



Thank You For Choosing Mobilla MBUDS 521

