



MBUDS 109 TWS Earbuds

User Manual



Appearance:



① Left Ear Piece

② Right Ear Piece

③ Multi-Function Touch Area

④ Left Earpiece Charging Socket

⑤ Right Earpiece Charging Socket

⑥ USB Type-C Charging Port

⑦ Microphone

⑧ Charge/Storage Case

Charging:

Charging Case:

Connect the case to a charger using a Type-C charger to charge the Charge/Storage Case.



Earbuds:

Place the earbuds in the charged Charge/Storage Case to charge the earbuds.

Note: Please take off the sticker peels attached to the earbuds before you charge them.

To Connect:

Charge the Charge/Storage Case and the Earbuds at least 70% before the first usage.

Pairing:

1. Take out the Earbuds from the Charge/Storage Case and place them in your ears.
2. Go to the Bluetooth settings of your device and switch it on.
3. Scan available devices.
4. Connect 'Mobilla MBuds 109' to your device.

After completing the pairing process, the TWS earbuds will connect to your device automatically when you take them out of the charging/storage case.



Smart Touch:

Play/Pause:

Single tap on the Multi-Function Touch Area.

Repeat Track:

Triple tap on the Multi-Function Touch Area of the left earbud.

Next Track:

Double tap on the Multi-Function Touch Area of the right earbud.

To Increase Volume:

Triple tap on the Multi-Function Touch Area of the right earbud.

To Decrease Volume:

Double tap on the Multi-Function Touch Area of the left earbud.

To Answer Calls:

Single tap on the Multi-Function Touch Area.

To Hang Up Calls:

Single tap on the Multi-Function Touch Area.

To Decline Calls:

Tap and hold on the Multi-Function Touch Area.

Power On/Off:

Long press for 4 to 5 seconds on the Multi-Function Touch Area.

Call Voice Assistant:

Long press for 2 to 3 seconds on the Multi-Function Touch Area.



Specifications:

- **Bluetooth Version:** 5.0
- **Music Playtime:** Up To 50 Hours
- **Sweat and Water Resistant:** IPX4 Rating
- **ENC:** Environmental Noise Cancellation



Thank You For Choosing Mobilla
MBUDS 109

