





# MBUDS 131 Wireless Earbuds

## User Manual





## Appearance:



- ① Left Ear Piece
- ② Right Ear Piece
- ③ Charge/Storage Case
- ④ Ear Piece Charging Socket
- ⑤ USB Type-C Charging Port
- ⑥ LED Battery Indicator
- ⑦ Microphone
- ⑧ Multi-Function Touch Area



## Charging:

### Charge/Storage Case:

Connect the case to a charger using a USB Type-C cable to charge the Charge/Storage Case.

The LED Display shows the battery percentage of the Charge/Storage Case.

### Earbuds:

Place the earbuds in the charged Charge/Storage Case to charge the earbuds.

**Note:** Please take off the sticker peels attached to the earbuds before you charge them.







## To Connect:

Charge the Charge/Storage Case and the Earbuds at least 70% before the first usage.

## Pairing:

1. Take out the Earbuds from the Charge/Storage Case and place them in your ears.
2. Go to the Bluetooth settings of your device and switch it on.
3. Scan available devices.
4. Connect 'Mobilla MBuds 131' to your device.

After completing the pairing process, the TWS earbuds will connect to your device automatically when you take them out of the charging/storage case.





## Smart Touch:

### **Play/Pause:**

Single tap on the Multi-Function Touch Area.

### **Repeat Track:**

Double tap on the Multi-Function Touch Area of the left earbud.

### **Next Track:**

Double tap on the Multi-Function Touch Area of the right earbud.

### **To Increase Volume:**

Triple tap on the Multi-Function Touch Area of the right earbud.

### **To Decrease Volume:**

Triple tap on the Multi-Function Touch Area of the left earbud.

### **To Answer Calls:**

Single tap on the Multi-Function Touch Area.

### **To Hang Up Calls:**

Single tap on the Multi-Function Touch Area.

### **To Decline Calls:**

Long press for 2 seconds on the Multi-Function Touch Area.

### **Call Voice Assistant:**

Long press for 2 seconds on the Multi-Function Touch Area of the right earbud.

## Specifications:

- Wireless Version: 5.1
- Music Playtime: Up To 24 Hours (at 50% volume)
- Charge Time: Up To 1 Hour
- Sweat-Resistant and Water-Resistant: IPX4 Rating



Available  
Colours:



Safari  
Green




Cobalt  
Blue



Jet  
Black



Ivory  
White



Coffee  
Brown