



*M*овіlla

I IOOI R

E ICIC F

USER MANUAL





APPEARANCE :

1	Left Ear Piece
2	Right Ear Piece
3	Multi-Function Touch Area
4	Left Earpiece Charging Socket
5	Right Earpiece Charging Socket
6	USB Type-C Charging Port
7	LED Battery Indicator
8	Microphone
9	Charge/Storage Case

WIRELESSEARBUDS

CHARGING:

Charge/Storage Case:

Connect the case to a charger using a USB Type-C cable to charge the Charge/Storage Case.

Earbuds:

Place the earbuds in the charged Charge/Storage Case to charge the earbuds. Note : Please take off the sticker peels attached to the earbuds before you charge them.

TO CONNECT :

Charge the Charge/Storage Case and the Earbuds at least 70% before the first usage.

Pairing:

- 1 Take out the Earbuds from the Charge/Storage Case and place them in your ears.
- 2 Go to the Bluetooth settings of your device and switch it on.
- 3 Scan available devices.
- 4 Connect 'Mobilla MBuds 511' to your device.

After completing the pairing process, the TWS earbuds will connect to your device automatically when you take them out of the charging/storage case.

SMART TOUCH:

Play/Pause : Single tap on the Multi-Function Touch Area

Repeat Track: Triple tap on the Multi-Function Touch Area of the left earbud.

Next Track: Triple tap on the Multi-Function Touch Area of the

To Increase Volume : Double tap on the Multi-Function Touch Area of the right earbud.

To Decrease Volume: Double tap on the Multi-Function Touch Area of the left earbud.

To Answer Calls : Single tap on the Multi-Function Touch Area.

To Hang Up Calls : Single tap on the Multi-Function Touch Area.

To Decline Calls : Tap and hold on the Multi-Function Touch

Power On/Off: Long press for 4 to 5 seconds on the Multi-Function Touch Area.

Call Voice Assistant: Long press for 2 to 3 seconds on the Multi-Function Touch Area.

SPECIFICATIONS :

- Bluetooth Version : 5.0
- Music Playtime : Up To 40 Hours
- Sweat and Water Splash Resistant : IPX5 Rating
- ENC : Environmental Noise Cancellation

≶ フ S S m \triangleright R ഗ

