



# MBUDS 101PRO

Wireless Earbuds

## User Manual



## Appearance:



- 1 Left Ear Piece
- 2 Right Ear Piece
- 3 Charge/Storage Case
- 4 Left Earpiece Charging Socket
- 5 Right Earpiece Charging Socket
- 6 USB Type-C Charging Port
- 7 Microphone
- 8 Multi-Function Touch Area



## Charging:

### Charge/Storage Case:

Connect the case to a charger using a USB Type-C cable to charge the Charge/Storage Case.



### Earbuds:

Place the earbuds in the charged Charge/Storage Case to charge the earbuds.

**Note:** Please take off the sticker peels attached to the earbuds before you charge them.

## To Connect:

Charge the Charging Case and the Earbuds at least 70% before the first usage.

## Pairing:

1. Take out the Earbuds from the Charging Case and place them in your ears.
2. Go to the Bluetooth settings of your device and switch it on.
3. Scan available devices.
4. Connect 'Mobilla MBuds 101Pro' to your device.



## Smart Touch:

### Play/Pause:

Single tap on the Multi-Function Touch Area.

### Repeat Track:

Double tap on the Multi-Function Touch Area of the left earbud.

### Next Track:

Double tap on the Multi-Function Touch Area of the right earbud.

### To Increase Volume:

Triple tap on the Multi-Function Touch Area of the right earbud.

### To Decrease Volume:

Triple tap on the Multi-Function Touch Area of the left earbud.

### To Answer Calls:

Single tap on the Multi-Function Touch Area.

### To Hang Up Calls:

Single tap on the Multi-Function Touch Area.

### To Decline Calls:

Double tap on the Multi-Function Touch Area.

### Call Voice Assistant:

Long press for 2 seconds on the Multi-Function Touch Area.



## Specifications:

- Bluetooth Version: 5.0
- Splash/Sweat Resistant: IPX5 Rating
- ENC ENABLED: Environmental Noise Cancellation
- Low Latency Upto 60ms





Thank You For Choosing Mobilla  
**MBUDS 101PRO**