

WIRELESS EARBUDS

MBUDS OVAL







APPEARANCE





Charge/Storage Case:

Connect the case to a charger using a USB Type-C cable to charge the Charge/Storage Case.

The LED Display shows the battery percentage of the Storage Case.

•





Place the earbuds in the charged Charge/Storage Case to charge the earbuds.

Note: Please take off the sticker peels attached to the earbuds before you charge them.

Charge the Charge/Storage Case and the Earbuds at least 70% before the first usage.

Pairing:

- 1. Take out the Earbuds from the Charge/Storage Case and place them in your ears.
- 2. Go to the Bluetooth settings of your device and switch it on.
- 3. Scan available devices.
- 4. Connect 'Mobilla MBuds Oval' to your device.

After pairing is completed, your device will connect automatically connect whenever plug them into your ears.



Play/Pause:

Single tap on the Multi-Function Touch Area.

Repeat Track:

Triple tap on the Multi-Function Touch Area of the left earbud.

Next Track:

Triple tap on the Multi-Function Touch Area of the right earbud.

To Increase Volume:

Double tap on the Multi-Function Touch Area of the right earbud.

To Decrease Volume:

Double tap on the Multi-Function Touch Area of the left earbud.

To Answer Calls:

Single tap on the Multi-Function Touch Area.

To Hang Up Calls:

Double tap on the Multi-Function Touch Area.

To Decline Calls:

Long press for 2 seconds on the Multi-Function Touch Area.

Call Voice Assistant:

Long press for 2 seconds on the Multi-Function Touch Area of the right earbud.

SPECIFICATION

Wireless Version: 5.1

Wireless Range: 10 Meters

Music Playtime: Up To 25 Hours (at 50% volume)

Charge Time: Up To 1 Hour

Driver Size: 10mm

Sweat & Water-Resistant: IPX4 Rating

