

BP40

Battery Powered Guitar Amplifier
OWNER'S MANUAL



深圳市酷乐科技有限公司

www.coolmusic-tech.com.cn www.coolmusic-tech.com

Q&As

1. Can not turn on the amp

Battery was dead; Try to connect the adapter and chek if the adapter indicator light works properly.

2. U disk can not record

Pls make sure the capacity of your U disk less than 32 GB;

The format of your U disk is incorrect, pls choose the U disk of FAT32.

3. Can not connect Bluetooth

Pls check wether the bluetooth trun on;

If the indicator light is always on after flashing, the bluetooth has been connected by other device;

Try another phone to connect it.

4. Battery problem

If the batteries dead for a long time, the batteries will be damaged.

The amp can use for 5-10 hours after full charged. The batteries can be changed, but you have to ask professional to do it.

5. No sound on the amp

Pls check the volume on, then pls the the adapter and the battery works normally.

6. Lound white noise

Pls pull all of the equipment out, incluing all of the musical instruments and adapter, if the issue can't be solve, pls contact the seller.

Technical Parameters

Model	BP-40	
Rated power	Rated : 40W	
The horn	Woofer: 8.0 inches Tweeter: 1.5 inches	
Frequency range	20 - 20kHz	
Lithium battery pack	4*18650 lithium battery + battery protection plate Voltage :14.8V Battery capacity :2600MA	
weight	6. 0KG	
adapter	18V/3A	

WELCOME!



Thank you for choosing to use BP40 battery powered guitar amplifier, After years of sound tests and explorations, our engineers and musicians finally developed the characteristics and advantages BP40. So we ensure that the amp will send out most beautiful voice for a variety of keyboards, acoustic guitar, microphone and other musical instruments.

Volume, bass and treble can be adjusted quickly and rechargeable lithium-ion batteries are built into this amp, which give it 5-10 hour of playing time. Maintained for 5-10 hour of working state after every charging. The handy USB port also allows you to charge your other devices when you're on the go.



- 1. When the speaker is not in use for a long time, charge it once every 6 months to prevent the speaker from being in a dead state for a long time and damaging the battery.
- 2. When the speaker is not used for a long time, charge it once every 6 months to fully charge it.
- 3. Please choose a DC, 18V, 3A adapter to charge the speaker (the adapter came with is DC 18V 3A)
- 4. Do not use AC adapter to charge directly, please charge it using the adapter provided by the manufacturer.
- 5. DI OUT jack can be connected to another speaker
- 6. We offer 1-year warranty, according to the time the customer receives the speake. (There is currently no specific place to register the warranty)

Channel 3 Channel 1/2 Channel 3 Channel 2 Reverb Gain Master Vol Treble Channel 3 Channel 3 Channel 1 Channel 2 Channel 3 Reverb Gain Bluetooth

• Power indicator:

- 1. Non-charging state: Display blue when power is enough; display purple when power
- 2.charging state: Purple light blinks during charging, turns to purple light(stop blink) after full-charged.

Bass: Low frequency signal control	Treble:middle High frequency signal control
Reverb: Timbre modification	Mode switching:Mp3/Bluetooth

• Recording button (this button is invalid when there is no U Disk inserted) How to turn on Recording Function?

- 1. Insert the U disk, click to start recording (the indicator light flashes red), click again to end the recording and play this recording (click again to start a new recording);
- 2. When playing a recording: double-click the recording button to delete the currently playing recording file, and long-press the recording button to switch between sequential play/single cycle (the indicator light is always on in purple during single cycle).
 - Indicator light:
 - 1.Bluetooth waiting for connection: Indicator Light blue flashing;
 - 2.Insert U disk / Bluetooth Connect to the mobile phone:Indicator light is normally on blue;
 - 3. Single cycle: Indicator light is normally on purple.



- USB input: The jack can read storage devices such as USB flash drive(Insert U disk automatically switch to MP3 mode)
 - Mode button:
 - 1.single press: Pause / play
 - 2.Long press:Bluetooth Open / close(No insert U disk)
 - 3.Long press:switch Bluetooth / MP3(insert U disk)
- single press:Next song Long press:volume increase
- Aux IN:Mobile phones or MP3 input


single press:Previous song Long press: volume discrease

How to turn on Bluetooth Function and connect with your devices?

- 1. Turn on the amplifier.
- 2. Long press the MODE button and turn on Bluetooth MODE.
- 3. Turn on the Bluetooth function of your device and choose the device with the name of coolmusic (Support recording software such as Douyin, Kugou, Kuaishou, National K Song, Sing Bar, etc.)

Schematic diagram of interface | Schematic diagram of interface

Battery Status: Blue light indicates battery is fully charged, and red light indicates low battery, requires charging. Charging Indicator: When the purple light is flashing, is charging, and when it's fully charged the lights stay steady purple.



POWER: power control, the associated power indicator

D.I out: listen port

Phones: headset output

18V DC input: Connect the output of adapter

9V DC output: The 9 v voltage supply to other equipment

Built-in MP3, Bluetooth and Record

★ Light weight and small size

Amazing sound and great look

★ Pretty versatile and capable