



ONLYX

USER MANUAL

INTRODUCTION TO **ARCH** PAKISTAN


“ Arch Pakistan’s Leading & Pioneer brand of bone conduction earbuds. With the largest collection of Open-ear & In-ear earbuds, we set the standard for innovation and choice.

With new designs launching every week, we ensure you always have access to the most advanced technology.

At Arch, we're dedicated to provide premium quality with unique designs, driven by our commitment to customer satisfaction.”

#ArchHaiPakistani

Product Structure



Product Specifications


| | |
|---------------------|----------------------|
| Bluetooth Version | 5.3 |
| Case Battery | 250mah |
| Transmission Radius | 10-15m |
| Music Time | About 6 hours |
| Charging Interface | USBType-C |
| Charging Time | About 1 hour |

Operations List

| | |
|------------------------------------|--|
| Pair | Open the case. Simply take out earbuds, hold for 4-5 seconds. Press button on back until light blinks. Turn on Bluetooth then connect to the device "MG23" |
| Music Play/Stop Call Answer/End | Click a left or right earbuds |
| Last or Next Song | Click 2 times to skip forward, 3 times to skip back |
| Volume UP/DOWN | Long press and drag upward to increase and downward to decrease volume. |
| Siri | Say "Hey Siri" to activate Siri |

Bluetooth Pairing

Take the earbuds out of the case. Turn on bluetooth on your device and search for new device “MG23” to connect.



Bluetooth Connected

Open the case and take out earbuds they will be automatically connected to the last bluetooth device.

Bluetooth Disconnected

Remove earbuds from ears and put them back in case then close it for disconnection. Earbuds will automatically disconnect when you are more than 10m away from the device. Get in range (10m) of the device to reconnect within 1 minute.

Charging Instruction

If your earbuds arrive with low batteries, It may be due to the long shipping process. But not to worry, First pay attention to the indicators provided. Here's how to interpret them:

Case Flashing

Charging: While charging, the case light indicator will blink to show that the charging process has begun.

If Earbuds Are Not Charging:

You may need to clean the charging contact with gentle touch and reposition them in the charging case to ensure proper contact with the charging pins

Charging Process

Find the USB charging port on your earbuds. This port is typically located on the bottom of case.

Take the provided USB Type-C cable and securely connect one end to a compatible power source, such as a USB wall adapter, computer, or power bank. Insert the other end of the USB Type-C cable into the charging port of your earbuds case. Ensure a firm connection is made to initiate the charging process.

Safety Instruction

Please observe the following precautions to avoid product damage.

1. Please do not put the product in back pocket to avoid squeezing, deformation or other faults when sitting down.
2. Please do not use the aircraft in the aircraft cabin. The impact of radiowaves may cause misoperation and accidents.
3. Please do not use this near medical devices. The impact of radiowaves may cause failure of cardiac pacemaker or other medical electronic devices.
4. The waterproof grade of this product is IPX4. Please choose the appropriate place to use this product.

Limited One Year Warranty

Our product is protected by a one-year limited warranty, effective from the date of purchase. Please refer to our website for comprehensive details

<https://arch-beat.com/>

OR Scan this QR code

