

Built-In Apartment Speaker

MODELS: N482BX SERIES DIRECT-A-COM 3

GENERAL INSTALLATION INFORMATION

1. Mount Apartment Speaker in NuTone rough-in frame for built-in installation. For surface mounting installation, mount Apartment Speaker in NuTone surface mount frame.
2. All necessary interconnecting wires and cables should be installed when the rough-in frames are mounted.
3. For system wiring diagrams concerning the optional Direct-A-Com 3 installations, see Installation Instructions on the NuTone Direct-A-Com Series 3.

MULTI-FLOOR & GARDEN APARTMENT INSTALLATION

Each Apartment Speaker connects to a speaker at the main entry. The following equipment may be used at the main entrance:

- (1) Entrance Directory as shown in Figure 1.
- (2) Mailboxes with pushbuttons and either built-in door speakers, or surface mounted door speaker.
- (3) Separate pushbuttons and either built-in or surface mounted door speaker.

SYSTEM WIRING (use recommended NuTone wire)



1. Refer to Figure 1 riser wiring detail. The 3-twisted pair cable (NuTone IW-6) is common between the Amplifier and all Apartment Speakers.
2. Common throughout the system:
 - (a) 18 gauge wire between Speaker Door Release Switch and Electric Door Release
 - (b) 18 gauge, 16vAC wire between Transformer and Speaker Buzzer and Speaker Door Release Switch.
3. Run individual 18 gauge wire between each Apartment Pushbutton and Speaker Buzzer.

APARTMENT SPEAKER WIRING

Refer to Figure 2.

1. Connect 3-twisted pair cable(s): ORANGE pair to ORN terminals, RED pair to RED terminals, BLACK pair to BLK terminals.
2. Connect one BROWN wire on Buzzer and one BROWN wire on Door Release Switch to 18 gauge, 16vAC wire from Transformer.
3. Connect other BROWN wire on Buzzer to 18 gauge wire from individual pushbutton at main entry.
4. Connect other BROWN wire on Door Release Switch to 18 gauge wire from DR-1 Electric Door Release at main entry.

NOTE: Use wire connectors, or splice and tape for wire connections in steps 2, 3 and 4 above.



NuTone®

Two Year Limited Warranty

WARRANTY OWNER: NuTone warrants to the original consumer purchaser of its products that such products will be free from defects in materials or workmanship for a period of two (2) years from the date of original purchase. **THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

During this two year period, NuTone will, at its option, repair or replace, without charge, any product or part which is found to be defective under normal use and service. **THIS WARRANTY DOES NOT EXTEND TO FLUORESCENT LAMP STARTERS OR TUBES, FILTERS, DUCT, ROOF CAPS, WALL CAPS AND OTHER ACCESSORIES FOR DUCTING.** This warranty does not cover (a) normal maintenance and service or (b) any products or parts which have been subject to misuse, negligence, accident, improper maintenance or repair (other than by NuTone), faulty installation or installation contrary to recommended installation instructions.

The duration of any implied warranty is limited to the one year period as specified for the express warranty. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

NUTONE'S OBLIGATION TO REPAIR OR REPLACE, AT NUTONE'S OPTION, SHALL BE THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY. NUTONE SHALL NOT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH PRODUCT USE OR PERFORMANCE. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. This warranty supersedes all prior warranties.

WARRANTY SERVICE: To qualify for warranty service, you must (a) notify NuTone at the address stated below or telephone 1/800-543-8687, (b) give the model number and part identification and (c) describe the nature of any defect in the product or part. At the time of requesting warranty service, you must present evidence of the original purchase date.

Date of Installation

Builder or Installer

Model No. and Product Description

IF YOU NEED ASSISTANCE OR SERVICE:

For the location of your nearest NuTone Independent Authorized Service Center:

Residents of the contiguous United States Dial Free 1-800-543-8687

Please be prepared to provide:

Product model number • Date and Proof of purchase • The nature of the difficulty

Residents of Alaska or Hawaii should write to: NuTone Inc. Attn: Department of National Field Service, 4820 Red Bank Road, Cincinnati Ohio 45227-1599.

Residents of Canada should write to: Broan-NuTone Canada, 1140 Tristar Drive, Mississauga, Ontario, Canada L5T 1H9.

Rev. 03/2001

Product specifications subject to change without notice.

NuTone®

4820 Red Bank Road, Cincinnati, Ohio 45227
Printed in U.S.A., Rev. 4/02, Part No. 46897