

FITTING GUIDE

SUPERRIP AGGRESSIVE POINT

Compatible with CaseIH machines

//AGRITUF

ONLY FARMERS ENDURE LONGER

AGRITUF SUPERRIP AGGRESSIVE POINT

THE LEADER IN LONGEVITY

AGRITUF points go the distance. Ensure proper fitting for the best results.



STEP ONE

Double check you have the correct bolts for the part.



STEP TWO

Slide the ripper point onto the shank, lining up the bolt holes.



STEP THREE

Fit the bolt through the lined up holes of the point and shank.



STEP FOUR

Place a washer on each end of the bolt and fasten with a lock nut, retaining the ripper point onto the shank.



STEP FIVE

Place the shank protector on the shank, lining up the top and bottom bolt holes.



STEP SIX

Install a roll pin through each of the two holes, securing the shank protector onto the shank.

/ AGRITUF SUPERRIP AGGRESSIVE POINT

MAKE AGRITUF DO THE HARD YARDS

**BOLT THREE POINTS ONTO YOUR
MACHINE, & PUT THEM IN HIGH
WEAR AREAS - THEN YOU'LL SEE
WHY THEY ARE THE BEST.**

Point one - in the centre

Point two - behind the wheel

Point three - outside edge

For further placement clarification refer to
numbers on right image.

**BETTER GEAR MAKES
A BIG DIFFERENCE TO
YOUR BOTTOM LINE.**





SUPERRIP AGGRESSIVE POINT PRODUCT CARE GUIDE

GENERAL CARE

Our superior performance is thanks to our unique chromium blend. To keep AGRITUF points performing at their peak, keep these in mind.

CARE WHEN LOWERING

Pay attention when lowering the machine on uneven surfaces where weight distribution onto a point(s) might cause damage.

DON'T DROP THEM

Avoid dropping AGRITUF points on hard surfaces - our points have been designed for point first soil penetrations.

DON'T OVER TIGHTEN

Caution when tightening with a impact gun. Do not over tighten.

MAINTAIN EQUIPMENT

While AGRITUF points go further than our competitors, they do still wear. To get the best results, make sure you're regularly checking & maintaining equipment.

EVEN TORQUE

Torque up bolts evenly with double bolt hole castings.

**/ AGRITUF SUPERRIP AGGRESSIVE POINT
BOLT FITTING GUIDE**

ATSRC7A-114	7 IN AGRITUF AGGRESSIVE CASE POINT 1 1/4	AGRITUF SHOULDER BOLT KIT
ATSRC10A-112	10IN AGRITUF AGGRESSIVE CASE POINT 1 1/2	1/2" X 1.75" LONG
ATSRC212-114	2.5 IN AGRITUF CASE SUPER RIP 1 1/4	1/2" X 2.0" OR 2.25" LONG
ATSRC7-112	7 IN AGRITUF CASE SUPER RIP 1 1/2	1/2" X 2.25" LONG
ATSRC7-114	7 IN AGRITUF CASE SUPER RIP 1 1/4	1/2" X 2.0" OR 2.25" LONG
ATSRC7A-112	7 IN AGRITUF AGGRESSIVE CASE POINT 1 1/2	1/2" X 1.75" LONG
ATSRD10-114	10 IN AGRITUF DEERE SUPER RIP 1 1/4	1/2" X 2.0" LONG
ATSRD212-114	2 1/2 IN AGRITUF DEERE SUPER RIP 1 1/4	1/2" X 2.0" LONG
ATSRD5-114	5 IN AGRITUF DEERE SUPER RIP 1 1/4	1/2" X 2.0" LONG
ATSRD7-114	7 IN AGRITUF DEERE SUPER RIP 1 1/4	1/2" X 2.0" LONG
AT SRL2400	SUPERRIP POINT TO SUIT LANDOLL 2400/2500	3/8" X 2.0" SPRING ROLL PIN
ATSRPC	CASE DMI SHIN PROTECTOR	3/8" X 2.0" SPRING ROLL PIN
ATSRSPD	JD SHIN PROTECTOR	3/8" X 2.25" SPRING ROLL PIN
ATSRSL2400	SHIN TO SUIT LANDOLL 2400/2500	INTERLOCKING WITH POINT
ATSRC8NT-34	8 IN AGRTUF SUPERRIP NO-TILL POINT 3/4	AGRITUF SHOULDER BOLT KIT
ATSP / ATSPC	AGRITUF CHROME SWEEPS	7/16" X 2.25" LONG



agrituf.com