


Supplies

Choose any of the below cleaning agents. Whatever you choose to use, make sure it's made to remove film, grease, oils, dried liquids, or debris. This also includes 70% Isopropyl Alcohol, CFC-free electronic contact cleaners with hexane.



Cleaning

1 Remove the device from the dock to expose the pogo pins located at the bottom of the dock. Simply spray a moderate amount of contact cleaner directly on the pogo pins.



2 After spraying the contact cleaner onto the pogo pins, take a Q-tip and gently wipe in between all the pins until all residue and excess contact cleaner is gone. Closely inspect the pogo pins for cleanliness and repeat the process until thoroughly cleaned.



- 1. For spills or accumulated dirt on the pogo pads, gently clean using contact cleaner or alcohol on a cotton swab. Use contact cleaner or alcohol to clean contacts.
- 2. For industrial and heavy use environments, clean pogo pad contacts on a regular basis.

3-year warranty on all electronic components/Lifetime Warranty on all non-electronic components

The exclusive NPI Lifetime Warranty states that all GDS® non-electronic components and parts are warranted against defect in materials and workmanship for the life of the product or part. NPI's Lifetime Warranty covers the product or its components only. The mount device is not covered under the Lifetime Warranty and will not be replaced if damaged as a result of mount failure. This warranty is expressly limited to persons in the United States, and all foreign countries who purchase GDS® for resale or use in the ordinary course of the buyer's business. This warranty does not cover any product or part that has been abused, worn out, heated, ground or otherwise altered, used for a purchase other than that for which it was intended, or used in a manner inconsistent with any instruction regarding its use.