

User Manual

Léger Floor Lamp





WWW.OZARKE.COM

Thank you for shopping with Ozarké, we really appreciate your business. Our goal is to provide an excellent customer service before, during and after delivery. We've included a guide on how to install this lamp, should you require additional assistance please feel free to email us and one of our customer service reps will reach out to assist you.

You can reach us via email at info@ozarke.com or via phone at +1-(800) 604-7271



WARNING!


1. Do not use the power supply beyond the specified range (85-265V).
2. Avoid scratching the surface and wires of the lamp during installation.
3. Do not install the lamp outdoors.
4. The lamp should not be close to corrosive chemical objects or gases.
5. It should not be washed with water. It can only be wiped with a clean soft cloth.



ASSEMBLY INVENTORY

Please check the assembly inventory. If you find anything missing reach out to our customer service team.

- 1 x LED Lamp
- 1 x Lamp Base
- 1 x Remote Control



REMOTE CONTROL INSTRUCTIONS

1- Please Install two AAA batteries. Once you have installed the batteries, point the remote at the light fixture and press the "On" button the light will come on. The remote should connect automatically once the batteries are installed (If the remote does not connect see step 2)

2- To connect the remote to the lamp, it must be done within the first 3 seconds after you power the fixture on, press the "on" button until the fixture flashes.

3- Once the light is on, use the "+" and "-" buttons on the remote to adjust the brightness. Pressing "+" will increase the brightness, while "-" will decrease it.

4- Once the light is on, use the "k+" and "k-" buttons on the remote to adjust the color temperature. Pressing "k+" will increase the temperature while "k-" will decrease it. Increasing the temperature will make the emitting color cold and decreasing the temperature will make the emitting color warm.

Helpful information:

1- ON: Turns the light on/ Connects to lamp/ Clears code

2- Off: Turns the light off

3- Wheel buttons: Adjusts temperature and brightness

4- 30%: 30% brightness

5- 80%: 80% brightness

6- Moon Button: 10% brightness

7- C: Cold White

8- W: Warm light

