

60V STEALTH Series All-Terrain 2-Seat Electric Youth Go-Kart

| Question | Answer |
|--|---|
| Having trouble connecting to the app? | <ol style="list-style-type: none">1. Make sure no one has previously connected to the Go-Kart2. Redownload the "smartG" app and follow the Quick Start Guide steps to connect " |
| Someone else is connected to the app and can't get them to disconnect? | <p>If someone has previously paired to the unit you are trying to connect to, please follow the steps to reset the unit:</p> <ol style="list-style-type: none">1. Power on the unit2. Push the brake over 6 times within the first 10 seconds of powering on the unit; then reconnect;3. With the unit powered off, press brake for 2 seconds and power on the unit (do not release the brake during this process) continue to press the brake for 10 seconds once unit is on.4. Follow directions in Quick Start Guide or App from here. |
| How do I connect to the speakers? | <p>Go into the Bluetooth settings in your phone. Ensure Bluetooth is turned on. The Go-Kart should appear with a title starting with GW-xxxxx (This connection is separate from the app connection)</p> |
| How do I switch from Eco to Sport mode? | <p>Within the "smartG" app, once you are paired, go to modes and select Eco or Sport. Please note, only one person can be paired to the Go-Kart through the app at a time.</p> |
| It Powered on, but won't go? | <p>Once you power on your Go-Kart, push the brake pedal once to disengage the auto park. Switch to drive and go.</p> |