

USER MANUAL




TAIL LIGHTS


GWJ2020-0012

2002-2006 Dodge Ram 1500
2002-2006 Dodge Ram 2500
2002-2006 Dodge Ram 3500

REQUIRED TOOLS



Phillips Screwdriver



Flathead Screwdriver

Installation Instructions

1. Remove the two bolts holding the taillights in.



2. Pull the taillight outward.



3. Push the locking tab on the main connector, push it down and out.



4. Unplug the main connector from the circuit plate.



5. Remove the circuit plate from the old taillight.



6



New Light



7. Install the circuit plate onto the new taillight.



8. Connect the main connector.



9. Install the new tail lights onto the car.



10



11. Repeat the steps 1~10 for the other side.



NOTE: Make sure all functions are working properly before driving.