USER MANUAL



TAIL LIGHTS




04-08 F150



Socket

Ratchet

Installation Instructions



3. Remove the light sockets by twisting and pulling outward.



2. Remove the tail light from the vehicle.



4. Remove the bulbs from the sockets. Auto



5. Push the taillight back into the truck.





8. Repeat the steps 1~7 for the other side.



