

Sew Your Own Reusable Fabric Easter Eggs



Cut (per egg):

(2) 5" x 6"

(2) 5" x 7"

Instructions:

- Place two 5"x7" pieces wrong sides together (WST).
- Fold each 5"x6" piece in half. Place on top of 5"x7" pieces with folds overlapping 3/4" in the middle.
- Trace paper egg template on top of fabric layers. Pin layers in place (one pin on each side where folds overlap).
- Sew on the line all around, backstitch where folds overlap.
- Trim seam allowance to 1/4" (optional: use pinking shears)
- Flip right sides out and you're finished! Repeat until you have as many eggs as you'd like.


Reusable Fabric Easter Egg

Cut:

(2) 5" x 6"

(2) 5" x 7"

Overlap flaps 3/4"



Print at 100%