






SETTING UP SPIKE

- 1. Turn Spike! over and turn off the power switch.
- 2. Use a phillips screwdriver to open the battery cover.
- 3. Connect the battery wire to Spike!'s connector as shown in the diagram.
- 4. Close the battery compartment, reinstall the screw, and switch the power switch to ON.



SETTING UP SPIKE'S REMOTE CONTROL


- Use a phillips screwdriver to open the battery cover.
- 2. Install 2x new AA batteries taking care to match the correct polarity (+/-).
- 3. Close the cover and reinstall the screw.




OPERATING SPIKE'S CONTROLLER

- For best results Spike needs to be within a 15' foot range of the controller.

Controller Functions



Spike Movement






Movement on 4 wheels



Movement on 2 wheels





Spining Front Wheels

Tip. Press the "Demo" button for Spike to show you all their tricks. Pressing the "Stop" button to cancel "Demo" mode.

CARE & MAINTENANCE

- Do not submerge the unit in any liquids.
- Keep the unit dry.
- Do not place the unit near powerful, un-shielded magnets.
- Do not expose the unit to extreme hot or cold temperatures.
- Do not hit, drop, or smash the unit with extreme force.
- Do not disassemble the unit for any reason.

NOT FOLLOWING THESE PRECAUTIONS WILL VOID YOUR WARRANTY.

CAUTIONS & WARNINGS

- Suitable for ages 4 and up. Adult supervision is always recommended.
- This product contains small parts which are a choking hazard. Keep away from small children.
- Manufacturers and dealers disclaim all responsibility for damage caused by misuse.
- Keep hair and loose clothing away fro Spike when powered on.
- If Spike will be stored and unused for an extended period of time, please remove the batteries
- Check the batteries regularly for potential leakage or corrosion that may occur.
- When installing the batteries carefully follow the polarity marking +/-.
- Do not mix different battery types.
- Remove exhausted or drained batteries.

WARRANTY

60 DAY LIMITED WARRANTY

Odyssey Marketing/ Odyssey Toys warrants to the original purchaser when used in the United States only, that this product shall be free of defects in material and workmanship. This warranty applies within 60 days of the original purchase date with normal home use. This warranty does not apply for commercial use of this product. Use outside of United States is not covered by this warranty. During the warranty period, we will at our discretion, repair or replace this product without charge, as long as the product has not been abused or mishandled as by our determination. Our determination shall be final and be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number which is issued by Odyssey Marketing's Customer Service Department.

Please contact Customer Service BEFORE returning any products or parts thereof. Once you have obtained a Return Authorization Number you will be provided a return address within the Customer Service email.

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire, or any acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modifications. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

** THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES. EXPRESSED OR IMPLIED INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.** ©2022 Odyssey Marketing Corp.



For Customer Service please email: Care@OdvssevTovs.com

Please note the units model number and name in your email: Model no. ODY-125 • Spike!

www.odysseytoys.com/support 1-(305)-933-4480 Hours of operation: 10:00am - 5:00pm EST

STOP

Please do not return this product to the store.



FCC STATEMENT: This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference receiver, including interference that may cause undesirable operation.







