



SETTING UP SPLIT WHEEL




- 1. Turn off the power switch.
- 2. Use a phillips screwdriver to open the battery cover.
- 3. Connect the battery wire to the Split Wheel's connector as shown on the diagram.
- 4. Close the battery compartment, reinstall the screw, and switch the power switch to On.



SETTING UP THE REMOTE CONTROL

- 1. Use a phillips screwdriver to open the battery cover.
- 2. Install 2x new AA batteries taking care to match the correct polarity (+/-).
- 3. Close the cover and reinstall the screw.



CHARGING THE SPLIT WHEEL'S BATTERY

- 1. Remove the battery from the Split Wheel as shown in the Split Wheel setting up instructions.
- 2. Connect the battery to the USB charging cord connector.




- 3. Plug the USB cord into a 5v1a USB charger.
- 4. The charger light will turn on to indicate charging. When the charger light goes out charging is complete and you can reinstall the battery.

👚 Tip. Full charge takes approx. 1hr


OPERATING SPLIT WHEEL


- For best results the Split Wheel needs to be within a 15' foot range of the controller.

Controller Functions




Split Wheel Movement













Spin Right






Turn Left






Turn Right






Reverse & Turn Left





Reverse & Turn Right







For Customer Service please email: Care@OdysseyToys.com

Please note the units model number and name in your email: Model no. ODY-114 • Split Wheel

www.OdysseyToys.com

CAUTIONS & WARNINGS

- Suitable for ages 8 and up. Adult supervision is always recommended.
- This product contains small parts which are a choking hazard. Keep away from small children.
- Manufacturers and dealers disclaim all responsibility for damage caused by misuse.
- Keep hair and loose clothing away from the Split Wheel when powered on.
- If Split Wheel will be stored and unused for an extended period of time, please remove the batteries.
- Check the batteries regularly for potential leakage or corrosion that may occur.
- When installing the batteries carefully follow the polarity marking +/-.
- Do not mix different battery types.
- · Remove exhausted or drained batteries.
- Do not exceed charging volts and amps of 5v1a.
- Do not leave charger connected or charge for more than 1hr.

CARE & MAINTENANCE

- Do not submerge the unit in any liquids.
- Keep the unit dry.
- Do not place the unit near powerful, un-shielded magnets.
- Do not expose the unit to extreme hot or cold temperatures.
- Do not hit, drop, or smash the unit with extreme force.
- Do not disassemble the unit for any reason.

NOT FOLLOWING THESE PRECAUTIONS WILL VOID YOUR WARRANTY.











