





















HITACHI EXCAVATOR PARTS---Controller

CMPH-A001	CMPH-A002	CMPH-A003	CMPH-A004
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel
EX100-2	EX100-2	EX100-2 EX120-2 EX200-2 EX220-2 EX100-3 EX120-3 EX200-3 EX200LC-3	EX100-2 EX120-2 EX200-2 EX220-2 EX100-3 EX120-3 EX200-3 EX220-3
9104905	9116366	9128976	9104918
CMPH-A005	CMPH-A006	CMPH-A007	CMPH-A008
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX300-2 EX320-2 EX340-2	EX100-2	EX100-2 EX120-2 EX200-2 EX220-2 EX100-3 EX120-3 EX200-3 EX200LC-3	EX100-3
9104918	9104910	9131577	9133701
CMPH-A009	CMPH-A010	CMPH-A011	CMPH-A012
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX100-3 EX100M-3	EX120-3	EX120-3	EX120-2
9133700	9131576	9131578	9104907
CMPH-A013	CMPH-A014	CMPH-A015	CMPH-A016
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX120-2	EX120-2	EX200-2 EX200LC-2	EX200-2 EX200LC-2
9116368	9131579	9104908	9116941
CMPH-A017	CMPH-A018	CMPH-A019	CMPH-A020
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX200-2 EX200LC-2	EX200-2 EX200LC-2	EX220-2	EX220-3 EX220LC-3
9125533	9104912	9104909 9117636 9125534 9104913	9133703

EMAIL: service@sinocmp.com sales@excavator-parts.com sales@cmpparts.com
 Whatsapp: +8615328181468 +8613242057399 +8613434784596
 Skype: Mou Mark(CMP) sinocmp-daisy

HITACHI EXCAVATOR PARTS---Controller

CMPH-A021	CMPH-A022	CMPH-A023	CMPH-A024
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel
EX220-3 EX220LC-3	EX300-2 EX300LC-2 EX320-2 EX340-2	EX300-3 EX320-3 EX340-3 EX300LC-3	EX300-3 EX300LC-3 EX320-3 EX340-3
9133702	9123938	9136787	9136786
CMPH-A025	CMPH-A026	CMPH-A027	CMPH-A028
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel
EX300-3 EX300LC-3	EX300-3 EX300LC-3 EX400-3 EX400-3C EX300-3C	EX400-3 EX400-3C EX400LC-3 EX400H-3 EX400LC-3C EX450H-3C EX400LCH-3	EX400-3 EX400-3C EX400LC-3 EX400H-3 EX400LCH-3
9153489	9153488	9142477	9133566
CMPH-A029	CMPH-A030	CMPH-A031	CMPH-A032
			
Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller
EX400-3 EX400LC-3 EX400H-3 EX400-3C EX400LC-3C EX450-3 EX450-3C	EX400-3 EX400LC-3 EX400H-3 EX400LCH-3 EX450-3 EX450LCH-3	EX550-3 EX550LC-3 EX600H-3 EX550 EX550L EX600H EX600LCH EX600LCH-	EX550-3 EX550LC-3 EX600H-3 EX550 EX550LC EX600H EX600LCH
9143297	9133567	9137152	9137151
CMPH-A033	CMPH-A034	CMPH-A035	CMPH-A036
			
Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi PVC Controller, Control Panel, Main Pump Controller	Hitachi EC Controller, EC Control Panel, Engine Controller, EPC Panel	Hitachi Excavator Controller, Control Panel, Computer Board
EX100WD-3	EX400-5 EX400LC-5 EX450LC-5 EX450H-5 EX450LCH-5	EX400-5 EX400LC-5 EX450LC-5 EX450H-5 EX450LCH-5	Zaxis ZX110-1 ZX120-1
9135614	9162392	9158859	9226740
CMPH-A037	CMPH-A038	CMPH-A039	CMPH-A040
			
Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board
Zaxis ZX100-1 ZX130-1	Zaxis ZX200/230/230LC/240/250/250LC-1	Zaxis ZX200-1 ZX200LC-1 ZX230-1	Zaxis ZX240-1
9226743	9226752	9226748	4445494

EMAIL: service@sinocmp.com sales@excavator-parts.com sales@cmpparts.com








Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy


HITACHI EXCAVATOR PARTS---Controller

CMPH-A041	CMPH-A042	CMPH-A043	CMPH-A044
			
Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board
Zaxis ZX250-1 ZX270-1 ZX270LC-1 ZX280LC-1	Zaxis ZX270-1 ZX270LC-1 ZX280LC-1 ZX280L-1	Zaxis ZX330-1 ZX330LC-1 ZX370-1 ZX350LC-1	Zaxis ZX450-1 ZX450LC-1 ZX450H-1
X9226754 9226754 0241117000	4428087	9226755 4428088	4428516 9227386
CMPH-A045	CMPH-A046	CMPH-A047	CMPH-A048
			
Hitachi Excavator EC Controller, Control Panel, Computer Board	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU
Zaxis ZX200-3 ZX240-3	Zaxis ZX220/230/270/330-1, ZX110/120/130/135US/200/240/270/330 -3	ZX200-3 ZX200LC-3 ZX210-3 ZX240-3 ZX250-3	Zaxis ZX240-3 ZX270-3
9292115	9292116 9263792	9292112	9281270
CMPH-A049	CMPH-A050	CMPH-A051	CMPH-A052
			
Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator EC Controller, Control Panel, Computer Board, CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU, Engine Controller	Hitachi Excavator Control Panel, Controller, Computer Board CPU, Engine Controller
ZX330-3 ZX330LC-3 ZX320LC-3 ZXS350LC-3	ZX225US-3 ZX225USLC-3	ZAXIS200 ZAXIS450 ZAXIS450LC ZAXIS600 ZAXIS160LC	ZAXIS160LC ZAXIS240 ZAXIS250 ZAXIS450 ZAXIS450LC
9260333	9263795	9194416	9212078
CMPH-A053	CMPH-A054	CMPH-A055	CMPH-A056
			
Hitachi Excavator Control Panel, Controller, Computer Board CPU, Engine Controller	Komatsu Monitor Assy, Monitor Panel, Instrument Panel	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU
ZAXIS160LC ZAXIS200 ZAXIS230LC ZAXIS330 ZAXIS330LC ZAXIS370	ZX200/240/330/270/450 -/240LC/250LC-3 ZX120/130W/160W/180W/210	EX100-3 EX200-3 EX200LC-3 EX200H-3 EX300-3 EX300LC-3	EX200-2 EX200LC-2 EX100-2 EX300-2 EX300LC-2 EX200-3
9239568	4631129 X4631129 025F41000 0500	4325825 4688258	4248572
CMPH-A057	CMPH-A058	CMPH-A059	CMPH-A060
			
Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU	Hitachi Excavator Control Panel, Controller, Computer Board CPU
EX60-5	EX200LC-5 EX200-5 EX210H-5 EX210LCH-5	EX120-5 EX130H-5	EX120-5
7376700	4372490 9164280	4369340	9164280 9148017

HITACHI EXCAVATOR PARTS----Controller

CMPH-A061	CMPH-A062	CMPH-A063	CMPH-A064
			
Hitachi Excavator Control Panel,Controller, Computer Board CPU	Hitachi Excavator Control Panel,Controller, Computer Board CPU	Hitachi Excavator Control Panel,Controller, Computer Board CPU	Hitachi Excavator Control Panel,Controller, Computer Board CPU
EX200-5	EX120-5 EX200-5	EX120-5 EX135USR	Zaxis ZX210-3 ZX200-3
9164280	9148016	9164279	4686916
CMPH-A065	CMPH-A066	CMPH-A067	
			
Hitachi Excavator Control Panel,Controller, Computer Board CPU	Hitachi Excavator Control Panel,Controller, Computer Board CPU	Hitachi Excavator Control Panel,Controller, Computer Board CPU	
Zaxis ZX270-3 ZX280-6	Zaxis ZX240-3	Zaxis ZX240-3	
8980806670	4686919	4635318	





















HITACHI EXCAVATOR PARTS----A/C Controller

CMPH-B001	CMPH-B002	CMPH-B003	CMPH-B004
			
Hitachi Excavator Air Conditioning Control Panel, A/C Controller	Hitachi Excavator Air Conditioning Control Panel, A/C Controller	Hitachi Excavator Air Conditioning Control Panel, A/C Controller	Hitachi Excavator Air Conditioning Control Panel, A/C Controller
Zaxis ZX75US-1/3 ZX135US-1/3 ZX225US-1/3 ZX135US-1/3	Zaxis ZX200-3 ZX240-3 ZX270-3	ZX160LC ZX120 ZX130	ZX450 ZX450LC EX1200-ZAXIS600 ZX600LC ZX800
4450315 4713662 4692239 4713980 4426048	4692240	4431080 146430-8272 237040-0090	4439093
CMPH-B005	CMPH-B006		
			
Hitachi Excavator Air Conditioning Control Panel, A/C Controller	Hitachi Kobelco Motor Control Mold, Accelerator Module		
ZX200-3 ZX240-3 ZX330-3 ZX270-3 ZX450-3 ZX240LC-3 ZX250LC-3	EX200-2/3 SK200-6		
4631128	SS2B003		



HITACHI EXCAVATOR PARTS----Monitor

CMPH-C001	CMPH-C002	CMPH-C003	CMPH-C004
			
Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen
ZX160LC/200/230LC/240/330/330LC/370/135US	Zaxis ZX200 ZX120 ZX240 ZX130 ZX135US ZX225US	Zaxis ZX200 ZX230LC ZXS330 ZX330LC ZXS370 ZX230 ZX350	Zaxis ZX-3
4488903 4483034	4450853	4646113	4652262 4631127 4653775 4684075
CMPH-C005	CMPH-C006	CMPH-C007	
			
Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen, Instrument Panel	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen, Instrument Panel	Hitachi Excavator Monitor, Display Panel, Cluster, LCD Screen, Instrument Panel	
EX100/120/200/220/300/400/550/600H -2/3	EX120-5 EX220-5 EX220LC-5 EX270-5 EX270LC-5 EX300-5 EX330LC-5	EX60-5 EX60LC-5 EX80-5	
4273796	4411757 4370905	4362249	

HITACHI EXCAVATOR PARTS----Motor

CMPH-D001	CMPH-D002	CMPH-D003	CMPH-D004
			
Hitachi Excavator Throttle Motor, Stepping Motor	Hitachi Excavator Throttle Motor, Stepping Motor	Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor
EX200-5-6 EX200-5 EX300-5 ZAX200-6 ZAX120/220/230/240/330-5	EX200-2 EX200-3 EX300-2 EX300-3 EX100-1 EX100-2 EX100-3	EX200-2 EX200-3	EX200-5 EX230LC-5
4360509 4614911	4257163 4188762 9094106 4709168		
CMPH-D005	CMPH-D006	CMPH-D007	CMPH-D008
			
Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor	Hitachi Excavator Blower Motor
ZX120-3 ZX330-3	ZAX200-3 ZX240-3	ZX460	ZX60 ZX70
			502725-1730 Y-SSMZ113-12
CMPH-D009	CMPH-D010	CMPH-D011	CMPH-D012
			
Hitachi Excavator Blower Motor	Hitachi Excavator Wiper Motor	Hitachi Excavator Wiper Motor	Hitachi Excavator Throttle Knob
ZX70LC ZX80 ZX135US ZX225US ZX70 ZX75US ZX85	ZAX200-3	ZX870-3	EX120-5 EX150LC-5 EX160LC-5 EX220-5 EX220LC-5 EX270-5 EX270LC-5
4475716		4709168	4341545
CMPH-D013	CMPH-D014	CMPH-D015	CMPH-D016
			
Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable
ZX200 ZX230LC ZX225US ZX230 ZX240LCH	EX120-2 EX100-2 EX100-3	ZX230LC ZX230 ZX240LCH ZX250 ZX250LC ZX270	EX1200-5 EX1200-5C EX1200-5D EX300-2 EX1200-6
4426564	4259859	4437891	4440505
CMPH-D017	CMPH-D018	CMPH-D019	CMPH-D020
			
Hitachi Excavator Throttle Cable	Hitachi Excavator Throttle Cable	Hitachi Excavator Accelerate Cable	Hitachi Excavator Throttle Cable
EX90 SK60-5	EX120-3 EX300-5	EX200-3	EX60

HITACHI EXCAVATOR PARTS----Motor

CMPH-D021	CMPH-D022
	
<p>Throttle Wiring Harness Governor Cable</p>	<p>Hitachi Excavator Throttle Cable</p>
<p>ZX450 ZX450LC ZX450H ZX600 ZX600LC ZX650H ZX800 ZX330LC</p>	<p>ZX135</p>
<p>4614911</p>	

HITACHI EXCAVATOR PARTS----Solenoid Valve

CMPH-E001	CMPH-E002	CMPH-E003	CMPH-E004
Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Valve	Hitachi Excavator Solenoid Valve
EX150-5 EX100-5 EX120-5 EX200-5 EX230-5	ZX200-3 ZX230-6	EX120-5 EX100-3 EX150LC-5 EX160LC-5 EX200-3 EX200LC-3	EX-5 EX135USR EX225USR
0671301	9218235	4255055	9745876 4367899
CMPH-E005	CMPH-E006	CMPH-E007	CMPH-E008
Hitachi Excavator Solenoid Valve	Hitachi Excavator High Speed Solenoid Valve, High Velocity Solenoid	Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve
Zaxis ZX450	EX100-2/3/5 EX120-2/3/5 EX200-2/3/5	ZX200-3 ZX210-3 EX400-3 EX400LC-3 EX400-3C EX400-5 EX400LC-5	ZX200 ZX230LC ZX230 ZX250 ZX250LC ZX350-3 ZX330-3
4469585	9147260 9120191 9120292 9098250	4368974	9218234
CMPH-E009	CMPH-E010	CMPH-E011	CMPH-E012
Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve	Hitachi Excavator Solenoid Valve
ZX60LC ZXS200 ZX230LC ZX330 ZX330LC ZX370 ZX120 ZX-3	EX100-3 EX200-3 EX200LC-3 EX200-2 EX200LC-2 EX100-2 EX220-3	EX100-3 EX200-3 EX200LC-3 EX200-2 EX200LC-2 EX100-2 EX220-3	EX100-3 EX200-3 EX200LC-3 EX200-2 EX200LC-2 EX100-2 EX220-3
4455991 9239590	4288336 9218359	4288337 9218367	4288336
CMPH-E013	CMPH-E014	CMPH-E015	CMPH-E016
Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY
Zaxis ZX-3	Zaxis ZX-3	EX200-5 EX330LC-5	EX220-5 EX300-5 EX300LC-5 EX350-5 EX370-5 EX345USR EX385USR
9254306 9312027	4400442 9218269 9311350	4330224 4330226 4396760	9218255 4396760 AT250108
CMPH-E017	CMPH-E018	CMPH-E019	
Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	Hitachi Excavator Solenoid Valve ASSY	
EX200-2 EX200LC-2	EX200-5	ZX330 ZX330LC ZX370 ZX350LC ZX350LCN ZX350LCH ZX350K	
4254647 9218370 4299959 AT158394 AT154742	9218312 9218382	9195243	

HITACHI EXCAVATOR PARTS----Conversion Kit

CMPH-F001	CMPH-F002	CMPH-F003	CMPH-F004
			
Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit
EX200-2	EX120-2	EX220-2	
CMPH-F005	CMPH-F006	CMPH-F007	CMPH-F008
			
Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit	Hitachi Excavator Conversion Kit
EX200-3	EX220-3	EX100-3	EX120-3

HITACHI EXCAVATOR PARTS----Wiring Harness

CMPH-H001	CMPH-H002	CMPH-H003	CMPH-H004
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
Zaxis ZX240-3 ZX270-3 ZX240LC-3 ZXS250LC-3 ZX250LCN-3 ZXS270LC-3	Zaxis ZX450 ZX450LC ZX450H ZX450LCH; ZX460LCH	EX225US EX1120-5 EX200-5	EX220-5
4658146	ZX450 ZX450LC ZX450H ZX450LCH; ZX460LCH	0002207 0001932	0002018
CMPH-H005	CMPH-H006	CMPH-H007	CMPH-H008
			
Hitachi Excavator Wiring Harness(External)	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
Zaxis ZX200 ZX200LC ZX210H ZX210LCH ZX210K ZX250 ZX240	ZX330-3 ZX330LC-3 ZX350-3 ZX350H-3 ZX350LCH-3	Zaxis ZX200 ZX230 ZX240 ZX250 ZX270 ZX280 ZX230LC ZX250LC	Zaxis ZX200 ZX230 ZX240 ZX250 ZX270 ZX280 ZX230LC ZX250LC
0004773 0003323	0005471	0003816	1027579
CMPH-H009	CMPH-H010	CMPH-H011	CMPH-H012
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
ZX200-3 ZX200LC-3 ZX210H-3 ZX210LCH-3 ZX210K-3 ZX240-3	ZX240-3 ZX330-3 ZX270-3 ZX240LC-3 ZX250LC-3 ZX250LCN-3	ZX200-1	ZX120-3 ZX270-3 ZX280-3 ZX200-3 ZX270LC-3 ZX280LC-3
0005473 0005472	0005458	4449447 4449447H	0006003
CMPH-H013	CMPH-H014	CMPH-H015	CMPH-H016
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
Zaxis ZX330 ZXS330LC ZX350H ZXS370 ZX350LC ZX350LCN	Zaxis ZX110 ZX120	Zaxis ZX160LC ZX200 ZXS230LC ZX120 ZX230 ZX240H ZX210 ZX250 ZX270	EX120-5 EX150LC-5 EX160LC-5 EX100-5 EX200LC-5 EX130H-5 EX110-5 EX210-
0004307	0004770	0003322	0002023
CMPH-H017	CMPH-H018	CMPH-H019	CMPH-H020
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
EX100-3 EX200-3 EX200LC-3 EX200H-3 EX120-3 EX200LCH-3	ZX450 ZXS450LC ZX450H ZX450LCH ZX460LCH	EX200-2 EX200LC-2 EX100-2 EX120-2	EX100-2 EX120-2
0001835 0001836	4447726	0001044	0001049

HITACHI EXCAVATOR PARTS----Wiring Harness

CMPH-H021	CMPH-H022	CMPH-H023	CMPH-H024
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
EX100-3 EX100M-3 EX120-3	EX200-2 EX200LC-2	EX220-2	EX220-2
0001847	4296868	0001065	0001066 4296408
CMPH-H025	CMPH-H026	CMPH-H027	CMPH-H028
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Hydraulic Pump Wiring Harness
EX300-2 EX300LC-2 EX300H-2 EX300LCH-2	EX300-3 EX300LC-3 EX300H-3 EX300LCH-3	EX400-3 EX400LC-3 EX400H-3 EX400-3C EX400LC-3C EX450H-3C EX450LCH-	EX120-2
0001534 0001535	0001660 0001661	0001302 0001303	0671301
CMPH-H029	CMPH-H030	CMPH-H031	CMPH-H032
			
Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness	Hitachi Excavator Wiring Harness
EX400-3 EX400LC-3 EX400-3C EX400LC-3C EX400-5 EX400LC-5	EX200LC-5 EX200-5 EX210H-5 EX210LCH-5 EX210-5	EX400-5 EX400LC-5 EX450LC-5 EX450-5 EX450LCH-5	EX400-5 EX400LC-5 EX450LC-5 EX450-5 EX450LCH-5
4295913	0003779	0002676 0003303 0003385	0002694 0003435
CMPH-H033	CMPH-H034	CMPH-H035	CMPH-H036
			
Hitachi Excavator Hydraulic Pump Wiring Harness	Hitachi Excavator External Wiring Harness	Hitachi Excavator Complete Wiring Harness	Hitachi Excavator Pump Wiring Harness
ZX200-3	EX120-2	EX120-2 EX100-2	EX200-3
0002018			
CMPH-H037			
			
Hitachi Excavator Hydraulic Pump Wiring Harness			
ZX200-1			

HITACHI EXCAVATOR PARTS----Relief Valve

CMPH-I001	CMPH-I002	CMPH-I003	CMPH-I004
			
Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX200-3 EX200LC-3 EX200H-3 EX200-2 EX200LC-2 EX220-3 EX220LC-3	ZX200 EX200LC-5 ZX225US ZX225USLC ZX200LC EX200-5 ZX200-3	EX220-5 EX220LC-5 EX270-5 EX270LC-5 EX280-5 EX200LC-5 EX230LC-5	EX120-2
4289602 4289406	4372038	4372034	
CMPH-I005	CMPH-I006	CMPH-I007	CMPH-I008
			
Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX200-5	EX300-3 EX300LC-3 EX300-3C EX310H-3C EX300-2 EX300LC-2 EX300H-2	EX200-1	EX200-2 EX200-3 EX200LC-3 EX220-5 EX220LC-5 EX270-5 EX270LC-5 EX300-
	4324535		9134147
CMPH-I009	CMPH-I010	CMPH-I010	CMPH-I012
			
Hitachi Excavator Service Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX120-5 EX150LC-5 EX160LC-5 EX100-5 EX100-5E ZX120 ZX120-E ZX130H	EX300-3 EX200-3 EX220-5 EX220LC-5 EX270-5 EX270LC-5 XXS200 ZX230LC	ZX200	ZX350-3 EX330-3 EX300-5 EX330LC-5 EX370-5 ZX330 ZX370 EX285USR
4372683	4372039		0719308 0719117
CMPH-I0013	CMPH-I014	CMPH-I015	CMPH-I016
			
Hitachi Excavator Main Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve	Hitachi Excavator Main Pressure Relief Valve
EX300-5 EX300LC-5 EX330LC-5 EX350H-5 EX370-5 ZX330 ZX330LC	EX200 EX200LC	ZX190W-3	EX200-2 EX300-5 EX300LC-5 EX330LC-5 EX200-5 EX370-5 ZX330 XXS330LC
0719010	4242176 4228354	9200504	0719116
CMPH-I017			
			
Hitachi Excavator Main Relief Valve			
ZX330 ZX330LC XXS350H ZX370 ZX350LC ZX350LCN			
0816204			

HITACHI EXCAVATOR PARTS----Sensor,Switch

CMPH-J001	CMPH-J002	CMPH-J003	CMPH-J004
Throttle Locator , throttle position sensor , Fitting Sensor, Accelerator locator	Throttle Locator , throttle position sensor , Fitting Sensor, Accelerator locator	Hitachi Excavator DP Sensor	Hitachi Excavator DP Sensor
EX200-5 ZX200-6 ZAX210/220/230/240/330	EX200-1 EX200-2 EX100-3 EX200-3 EX200LC-3 EX200H-3 EX300-3	EX120-2 EX200-2 EX120-3 EX200-3 EX200-5 EX220-5 EX300-2 EX300-3	EX120-2 EX120-3 EX200-2 EX200-3
4614912	4257164	4339559 9101532 9102068	590332
CMPH-J005	CMPH-J006	CMPH-J007	CMPH-J008
Hitachi Angle Sensor Angular sensor	Hitachi Angle Sensor Angular sensor	Hitachi Angle Sensor Angular sensor	Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor
EX120-2 EX120-3 EX200-2 EX200-3 ZX450 ZX450LC ZX600 ZX800	EX120-2 EX120-3 EX200-2 EX200-3 ZX400-3 ZX400LC-3 ZX200LC-3	EX120-2 EX120-3 EX200-2 EX200-3	EX200-1 EX200-2 EX200-3 EX200-5
4444902	9102385 9101533	4716888	1-82410160-1 1-82410160-0 1-82410044-0
CMPH-J009	CMPH-J010	CMPH-J011	CMPH-J012
Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor	Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor	Oil Pressure Switch,Oil Pressure Sensor ,Hitachi Hydraulic Pressure Sensor	Hitachi Excavator RPM Revolution Speed Sensor
EX200-2 EX200-3 EX300-3	EX120-5 EX100-3 EXE150LC-5 EX200-3 EX220-5 EX200LC-3 EX220LC-5	EX200-5	EX200-1 EX200-2 EX200-3 EX200-5 EX100-3 EX220-5 EX270-5
4259333	4259787	6732-81-3140 08073-10505	4265372
CMPH-J013	CMPH-J014	CMPH-J015	CMPH-J016
Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm
EX120-5 EX400-5 EX200-2/3/5 EX300-2/3/5 ZX330 ZX450	EX200-2 EX200-3 EX200-5 EX120-5 EX100-3 EX220-5 EX220LC-5	ZX200 ZX450 ZX1600 ZX800 ZX70LC ZX80 ZX160LC	EX100-3 EX200-3 EX200LC-3 EX400-3 EX400LC-3
4371318	4257129	4436537	4250260 179700-0050
CMPH-J017	CMPH-J018	CMPH-J019	CMPH-J020
Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Excavator Water Temperature Sensor Alarm	Hitachi Crankshalf sensor
EX200-2 EX200-5 EX200-3	ZX200-1	EX200-5 EX300-5	ZX240-3 ZX330-3 ZX270-3 ZX450-3 ZX850-3 ZX250LC-3
1-83161019-1	1-83161033-0	8-97125601-1	4657944 8-98014831-0

HITACHI EXCAVATOR PARTS----Sensor, Switch

CMPH-J021	CMPH-J022	CMPH-J023	CMPH-J024
			
Hitachi Excavator Pressure Switch	Hitachi High-Pressure Common Rail Sensor	Hitachi Pressure Sensor(distributor)	Hitachi Pressure Sensor(large pump) /Switch
EX200-3 EX200-2 EX200-5 EX120-2 EX120-3 EX120-5 EX400-3	ZX330-3	ZX200-3 ZX230-3 ZX450-3 ZX450 ZX600 ZX800 EX1200-5 EX1900-5	ZX450 ZX600 ZX800 ZX160 ZX200 ZX120-3 EX200-2/3/5 EX300-2/3/5
4254563	10L05840	4436535	4436536
CMPH-J025	CMPH-J026	CMPH-J027	CMPH-J028
			
Hitachi Pressure Switch(Distributor)	Hitachi Excavator Pressure Sensor	Hitachi Excavator Pressure Sensor	Hitachi Excavator Pressure Switch
EX60-5 EX100-5 EX120-5 EX200-5 EX220-5 EX270-5 EX150LC-5	EX200-2 EX200LC-2 EX100-2	EX200-2/3/5 EX300-2/3/5 ZX450 ZX600 ZX80 ZX210 ZX270	EX120-5 EX270-5 EX220LC-5 EX300-5 EX200LC-5 EX200-5 EX100-5
4353686	4339754 4248773	4436271 4355012	
CMPH-J029	CMPH-J030	CMPH-J031	CMPH-J032
			
Hitachi Excavator Pressure Sensor(distributor)Pressure Switch	Hitachi Excavator Pressure Sensor	Hitachi Excavator Pressure Sensor	Switch 4483285 and Dial Knob 4482656
EX200-2 EX200-3 EX120-5 EX200-5 EX220-5 EX270-5 EX100-5	EX200LC-2 EX100-2 EX200-2 EX200-3 EX120-5 EX200-5 EX100-5 EX270-5	EX200-5 EX120-5 EX220-5 EX270-5 EX100-5 EX150LC-5 EX220LC-5	ZX200 ZX135US ZX225US
20PS586-19F82	4333040	4380677 20PS586-23	4483285
CMPH-J033	CMPH-J034	CMPH-J035	CMPH-J036
			
Hitachi Excavator Ignition Switch	Hitachi Excavator Ignition Switch	Hitachi Excavator Ignition Switch	Hitachi Excavator Ignition Switch
EX200-2 EX200-3 EX200-5 EX300-3 EX3500-3 EX5500-3 EX100-2 EX300-2	EX200-1	ZX200LC ZX250 ZX350 ZX240F-3 ZX290F-3	EX100-3 EX200-3 EX300-3 EX200 EX200-2 EX200LC-3
4250350 4448303		4477373	4164695
CMPH-J037	CMPH-J038		
			
Hitachi Excavator Ignition Switch	Hitachi Excavator Ignition Switch		
Zaxis ZX	EX200-2/3/5		

HITACHI EXCAVATOR PARTS----Relay

CMPH-K001	CMPH-K002	CMPH-K003	CMPH-K004
			
<p>Hitachi Excavator Starter Relay</p>	<p>Hitachi Excavator Battery Relay</p>	<p>Hitachi Excavator Relay</p>	<p>Hitachi Excavator Relay</p>
<p>EX200-2 EX200-3 EX200-5 EX120-5 EX100-3 EX220-5 EX220LC-5 EX200LC-</p>	<p>EX120-5 EX100-3 EX150LC-5 EX200-3 EX300-3 EX200LC-3 EX300LC-3</p>	<p>EX120-2 EX200-3 EX300-3 EX200-2 EX100-2 EX400 EX1000 UH181 UH501</p>	<p>ZX450 ZX450LC ZX600 ZX600LC ZX800 ZX70LC ZX80 EX1200-5</p>
<p>4251588 4251587 5AT02-261022</p>	<p>4255762 BR-262 08088-30000</p>	<p>4191999 4325797 1-82550192-1</p>	<p>4436534</p>
<p>CMPH-K005</p>			
			
<p>Hitachi Excavator Relay</p>			
<p>MR5A016B2</p>			

HITACHI EXCAVATOR PARTS----Pump

CMPH-L001	CMPH-L002	CMPH-L003	CMPH-L004
			
Hitachi Excavator Pilot Pump	Hitachi Excavator Gear Pump	Hitachi Excavator Gear Pump	Hitachi Excavator Gear Pump
EX100-2 EX100M-2 EX120-2 EX200K-2 EX220-2 EX200-2 EX200-3E	EX100-3/5 EX110-5 EX200-3/5 EX220-3/5 EX225 EX230-5 EX270-5 EX280 EX400-	EX200-1 EX220-1 EX270-1 EX300-1/2/3/3C/5 EX330LC-5 EX400-1 EX550-	UH082LC UH261 UH172 UH07-5 UH123 UH10-7 UH23 UH07-7 UH07LC-7 UH083
4255303 9218004	4276918 9218005	4181700 9217993	4035495
CMPH-L005	CMPH-L006	CMPH-L007	CMPH-L008
			
Hitachi Excavator Gear Pump	Hitachi Excavator Oil Pump	Hitachi Excavator Oil Pump	Hitachi Excavator Oil Pump
EX30-2 EX35-2	EX100 EX120	EX200-1 EX200-2	
			8-98009397-1
CMPH-L009	CMPH-L010	CMPH-L011	CMPH-L012
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
4BG1	4BG1T	4HF1	4JB1
CMPH-L013	CMPH-L014	CMPH-L015	CMPH-L016
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
4JG2	4ZC1	4ZD1	4ZE1
CMPH-L017	CMPH-L018	CMPH-L019	CMPH-L020
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
6BD1	6BD1H	EX200-2/3 6D16T	6HE1T
		4210164	





HITACHI EXCAVATOR PARTS----Pump

CMPH-L021	CMPH-L022	CMPH-L023	CMPH-L024
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
6QA1	6RBIT	C190	C240
CMPH-L025	CMPH-L026	CMPH-L027	CMPH-L028
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
DA220	DA640	EX120-2	EX200-1 6BD1T
CMPH-L029	CMPH-L030	CMPH-L031	CMPH-L032
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
EX200-2 6BD1T	EX200-5 6BG1T	EX300-3 6SD1T	EX300-5 6SD1T
CMPH-L033	CMPH-L034	CMPH-L035	CMPH-L036
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
FSR113 6BF1	EX120-2 EX120-5 4BG1	4HK1	NKR 4JB1T
CMPH-L037	CMPH-L038	CMPH-L039	CMPH-L040
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
TCM C240	UBS 6VD1	EX200-5 6BG1	EX220-5 H07CT
		1-13650017-1	




HITACHI EXCAVATOR PARTS----Pump

CMPH-L041	CMPH-L042	CMPH-L043	CMPH-L044
			
Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump	Hitachi Excavator Water Pump
EX300-2/3 6SD1	ZX330	ZX330 6HK1T	4BD1 4BC2
1-13610944-0	1-13650133-0		
CMPH-L045	CMPH-L046	CMPH-L047	
			
Hitachi Main Hydraulic pump	Hitachi Excavator Regulator Pump	Hitachi Excavator Piston Pump	
EX300 EX300LC EX300H EX300LCH			
9075752	9266177	PVK-2B-505-N-4962F	

HITACHI EXCAVATOR PARTS----Injector


CMPH-M001	CMPH-M002	CMPH-M003	CMPH-M004
			
Hitachi Excavator Injector	Hitachi Excavator Injector	Hitachi Excavator Injector	Hitachi Excavator Injector
ZX200-3 ZX240-3 ZX330-3 ZX350-3	ZX470-3	ZX350-3	ZX-3
8-98284393-0 095000-0660	8-97603415-7	8-98284393-0	095000-5474

HITACHI EXCAVATOR PARTS----Seal Kit

CMPH-N001	CMPH-N002	CMPH-N003	CMPH-N004
			
Hitachi Bucket Cylinder Seal Kit	Hitachi Excavator Arm Cylinder Seal Kit	Hitachi Excavator Boom Cylinder Seal Kit	Hitachi Excavator Travel Motor Seal Kit
		EX60-3	EX60-5
CMPH-N005	CMPH-N006	CMPH-N007	CMPH-N008
			
Hitachi Excavator Center Joint seal kits	Hitachi Excavator Main Pump Seal Kit	Hitachi Excavator swing motor Seal Kit	Hitachi Excavator Track Adjuster Seal Kit
CMPH-N009	CMPH-N010		
			
GASKET KIT	Hitachi Excavator Gear Pump Seal Kit		


HITACHI EXCAVATOR PARTS---Hydraulic Parts

CMPH-Q001



HPV050/102/105/118/135 (EX200-5/Z20-5, ZXIS200/Z20/Z30)

ITEM	DESCRIPTION	QUANTITY	REMARK
1	SERVO PISTON	2	
2	SERVO PISTON PIN	2	
3	HEAD COVER	1	
4	VALVE PLATE (R)	1	
5	SNAP RING	12	
6	BOLT OF VALVE PLATE	4	
7	ROTOR	2	
8	LINK OF VALVE PLATE	4	
9	PIN OF LINK	4	
10	COIL SPRING	2	
11	PISTON	14	
12	FEED BACK LEVER	2	
13	VALVE PLATE (L)	1	
14	CENTER PIN	2	
15	PIN OF CENTER PIN	2	
16	DRIVE SHAFT (R)	1	
17	DRIVE SHAFT (L)	1	
18	LOCK NUT	2	
19-A	PIN OF FEED BACK-A	2	
19-B	PIN OF FEED BACK-B	2	




Hitachi Excavator Hydraulic Pump Spare Parts

HPV050/102/118/135

EX200-5 EX220-5 ZX200 ZX220 ZX230

CMPH-Q002



HPV091DS/ES(EX100-2/EX100-3/5)

ITEM	DESCRIPTION	QUANTITY	REMARK
1	HEAD COVER	1	
2	SERVO PISTON	1	
3	SERVO PISTON PIN	1	
4-A	VALVE PLATE(ES-TYPE)	1	
4-B	VALVE PLATE(DS-TYPE)	1	
5	ROTOR	1	
6	COIL SPRING	1	
7	PISTON	14	
8	CENTER PIN	2	
9	PIN OF CENTER PIN	2	
10	HOLDER OF CENTER PIN	1	DS-TYPE
11	BALL OF CENTER PIN	1	DS-TYPE
12	DRIVE SHAFT(ES-TYPE)	1	
13	DRIVE SHAFT(DS-TYPE)	1	
14	BOLT OF VALVE PLATE	1	
15	LOCK NUT	2	



Hitachi Excavator Hydraulic Pump Spare Parts

HPV091DS/ES

EX100-2 EX100-3 EX100-5 EX200-2 EX200-3 EX220-2 EX220-3

HITACHI EXCAVATOR PARTS----Others

CMPH-P001	CMPH-P002	CMPH-P003	CMPH-P004
			
Throttle Motor Gear	Rubber Gear	Fuel tank cap	Hitachi Handle
EX120-5/60EX200-5/6	ZX-5	ZX-5	EX300-5
CMPH-P005	CMPH-P006	CMPH-P007	CMPH-P008
			
Hitachi Excavator Air Conditioning Belt Tensioner	Hitachi Excavator Diode	HITACHI Hydraulic Oil Dipstick	Hitachi Hydraulic Oil Dipstick
8-94399957-0 4346770	EX200-3 EX400-3 EX750-5 EX1100-5 EX200LC-3 EX550-5 4288109		
CMPH-P009	CMPH-P010	CMPH-P011	CMP-K025
			
Hitachi Excavator Fuel Gauge Level	Hitachi Fuel Gauge Level For JOHN DEERE Excavator	Hitachi Excavator Radio	Hitachi Excavator Fuse Panel Box
	EX200-23 EX120-3 6BD1 8033923	ZX250LC-3 YA00010687	ZX-1
CMP-K026	CMP-K027	CMP-K028	CMP-K029
			
Hitachi Excavator Fuse Panel Box	Hitachi Excavator Ring	Hitachi Excavator Radiator	Hitachi Excavator Oil Seal
ZX-3	EX100-3 EX200-3 EX200-2 EX100-2 ZX200 ZX230LC EX200LC-3 4339171	ZX200-3 ZX240-3 ZX330-3 ZX270-3 ZX250-3 4647814	EX100-3 EX200-3 EX220-3 EX220LC-3