

## Volvo EXCAVATOR PARTS---Controller





CMPV-A001	CMPV-A002	CMPV-A003	CMPV-A004
Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V
EC160BLC EC160	EC210B EC210BLC EC240B EC270B EC290B EC330B EC360B EC460B	L60E L70E L120	EC360B EC360BLC
60100002 VOE 60100002/P02/P04/P05/P06/P11	60100002 VOE 60100002/P02/P04/P05/P06/P11	60100002/ 3161983/ VOE 20577135	20582958/ VOE 20582958/P06
CMPV-A005	CMPV-A006	CMPV-A007	CMPV-A008
Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V
EC290B EW145B	EC460B EC360B EC330B	EC140B EC140 EC160BLC EC160 EC180B EC180BLC	EC210B EC210BLC EC240B EC240BLC EC270B EC270BLC EC290B EC290BLC
20577135/ VOE 20577135/P02	20577131/ VOE 20577131	60100000 VOE 60100000/P01/P02/P03/P04/P11	60100000 VOE 60100000/P01/P02/P03/P04/P11
CMPV-A009	CMPV-A010	CMPV-A011	CMPV-A012
Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V
EC330B EC330BLC EC360B EC360BLC EC380B EC380BLC EC460B	EC210C EC210CLC EC290C EW180C EC210D	L60F L20E L120E	EC140B EC140 EC140BLC EC160B EC160 EC160BLC EC180B EC180BLC
60100000 VOE 60100000/P01/P02/P03/P04/P11	60100000 VOE 60100000/P01/P02/P03/P04/P11	60100000 VOE 60100000/P01/P02/P03/P04/P11	VOE 14518349/ VOE 14514090
CMPV-A013	CMPV-A014	CMPV-A015	CMPV-A016
Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo ECU Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V
EC210 EC210B EC210BLC EC240 EC240B EC240BLC EC290B EC290BLC	EC330B EC330BLC EC330 EC360 EC360B EC360BLC EC380B EC380BLC	EC240B EC290B EC330B EC360B EC460B	EC210B EC240B EC290B EC330B EC360B EC380B EC460B
VOE 14518349/ VOE 14514090	VOE 14518349/ VOE 14514090	14531360/ VOE14531360	14594697/ VOE 14594697
CMPV-A017	CMPV-A018	CMPV-A019	
Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo VECU, V-ECU, Controller Control Panel Computer Board 24V	Volvo ECU, E-ECU, Controller Control Panel Computer Board 24V	
EC360D EC380D EC480DL	EC220D EC200D EC350D EC380D EC480D	EC700 EC700B D16E	
14594707/ VOE14594707	14594708/ VOE14594708	20814604/ VOE 20814604	

EMAIL: [service@sinocmp.com](mailto:service@sinocmp.com) [sales@excavator-parts.com](mailto:sales@excavator-parts.com) [sales@cmpparts.com](mailto:sales@cmpparts.com)

Whatsapp: +8615328181468 +8613242057399 +8613434784596

Skype: Mou Mark(CMP) sinocmp-daisy

## Volvo EXCAVATOR PARTS---Controller

CMPV-A021	CMPV-A022	CMPV-A023	CMPV-A024
			
<p>Volvo Air Conditioner Control Panel Controller, A/C Controller DC: 24V</p>	<p>Volvo Air Conditioner Control Panel Controller, A/C Controller DC: 24V</p>	<p>Volvo 60100000 ECU Controller Plug</p>	<p>Volvo VECU Controller Plug</p>
<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>	<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>	<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>	<p>EC140B EC160B EC180B EC210B EC460B EC360B EC330B EC290B</p>
<p>14590052/ 14541344 VOE14541344 VOE14590052</p>	<p>14631179/ 14520415 VOE14631179/ VOE14520415</p>		





## Volvo EXCAVATOR PARTS---Monitor

CMPV-B001	CMPV-B002	CMPV-B003	CMPV-B004
			
Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V
EC140 EC140BLC EC140B	EC160B EC160BLC EC210B EC210BLC EC240B EC240BLC EC290B EC290BLC	EC360B EC360BLC EC380B EC380BLC EC460B EC460BLC	EW180B
VOE 14390065/P03/P02 VOE 14636301/ VOE 14527149	VOE 14390065/P03/P02 VOE 14636301/ VOE 14527149	VOE 14390065/P03/P02 VOE 14636301/ VOE 14527149	14390065/ VOE 14390065/P03/P02
CMPV-B005	CMPV-B006	CMPV-B007	CMPV-B008
			
Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V	Volvo I-ECU Monitor Display Panel Gauge Panel 24V
EC160B EC210B EC290B EC330B EC360B EC380B EC460B	EC140B EC160B EC210B EC290B EC330B EC360B EC380B EC460B	EC360C EC240CL EC210D EC220D EC240D EC380D	EC360C EC240CL EC220D EC210D EC240D EC360D EC380D EC480D
1048069137DE/ 1145086420DE	14515555/ 14527158/ 14521370 VOE14527158/VOE14515555/VOE14521370	14585030/ 14609502/ 14640101 VOE14585030/VOE14609502/VOE14640101	14640102/ 14544928/ 14630801/ 14609611
CMPV-B009	CMPV-B010		
			
Volvo Monitor LCD	Volvo Monitor Plug		
EC140B EC160B EC210B EC290B EC330B EC360B EC380B EC460B	EC140B EC160B EC210B EC290B EC330B EC360B EC380B EC460B		

## Volvo EXCAVATOR PARTS---Sensor and Switch

CMPV-C001	CMPV-C002	CMPV-C003	CMPV-C004
			
Volvo Water Temperature Sensor	Volvo Revolution Roarty Speed Sensor	Volvo Oil Pressure Sensor	Volvo Prime Level Sensor
EC240B EC290B EC330B EC360B EC460B EC700B	EC140B EC160B EC180B EC210B EC240B EC290B	Volvo Track, Wheel Loaders L180E L150E	EC210BLC
14508670/ VOE 14508670	14505855/ VOE14505855	20706889/ 20374280/ 20478260/ 20700060	VOE21391697/ VOE20840227
CMPV-C005	CMPV-C006	CMPV-C007	CMPV-C008
			
Volvo Warning Level Sensor	Volvo Excavator Oil Pressure Sensor	Volvo Excavator Oil Pressure Sensor Switch	Volvo Excavator Oil Pressure Sensor
EC290B EC240B	EC700B EC460B EC360B EC330B	EW140B	EC460B EC360B EC330B
VOE11170064	21302639/ 20898038 20484678/ 20829689/ 21746206	VOE20585158	VOE1077574
CMPV-C009	CMPV-C010	CMPV-C011	CMPV-C012
			
Volvo Excavator Pressure Sensor	Volvo Water Temperature Sensor 16MM	Volvo Excavator Oil Level Sensor	Volvo Excavator Pressure Sensor
110R-000096/ 29003981	EC210B E290B	VOE11423761	EC290 EC330
			VOE14529294
CMPR-C013	CMPV-C014	CMPV-C015	CMPV-C016
			
Volvo Water Temperature Sensor	Volvo Excavator Oil Level Sensor	Volvo Water Temperature Sensor	Volvo Excavator Oil Pressure Sensor
EC210B EC140B	VOE21391695/ VOE21391697	VOE4436537	VOE 20796744
VOE20513340			
CMPV-C017	CMPV-C018	CMPV-C019	CMPV-C020
			
Volvo Excavator Oil Pressure Sensor	Volvo Excavator NEW Oil Pan Pressure Sensor	Volvo Crankshaft Position Sensor	Volvo Crankshaft Speed Sensor
VOE 20886108	Truck D12 D13 EC300D	EC210 EC290	EC240 EC290
	VOE 21634021	VOE20820494	VOE 20450707










## Volvo EXCAVATOR PARTS----Sensor and Switch

CMPV-C021	CMPV-C022	CMPV-C023	CMPV-C024
			
<p>Volvo Crankshaft Position Sensor</p>	<p>Volvo Crankshaft Position Sensor</p>	<p>Volvo Excavator Ignition Switch</p>	<p>Volvo Excavator Switch</p>
		<p>EC160B EC210 EC290 EC240B EC330B EC360B</p>	
<p>VOE0281002410/ 4890189</p>	<p>VOE20482772</p>	<p>VOE 14826158/ VOE 14529152</p>	<p>VOE14508635</p>

## Volvo EXCAVATOR PARTS---Main valve and Solenoid

CMPV-D001	CMPV-D002	CMPV-D003	CMPV-D004
			
Volvo Excavator Hydraulic Pump Solenoid Valve	Volvo Excavator Solenoid Valve Coil	Volvo Excavator Solenoid Valve Coil 24V	Volvo Excavator Solenoid Valve
EC210B EC290B	EC210B EC160B EC180B EC135B EC140B EC700B	EC210 EC240	EC210B EC140B EC240B EW130
KDRDE5K-20/40C04-109	14527267/ VOE14527267	VOE 14550884	VOE14526664/ 14526664
CMPV-D005	CMPV-D006	CMPV-D007	CMPV-D008
			
Volvo Excavator Main Relief/Control Valve	Volvo Excavator Main Relief/Control Valve	Volvo Excavator Main Relief/Control Valve	Volvo Excavator Main Relief/Control Valve
DH220-5 DH225-7 R225-7 HD820 SH120 EC210 EC240	EC210B EC240B EC210	EC210B EC240B EC210	EC460
	SA8230-21640/ 8230-21640	14518516/ SA8230-27400	
CMPV-D009	CMPV-D010	CMPV-D011	CMPV-D012
			
Volvo Excavator Service Relief/Control Valve	Volvo Excavator Rotary Overflow Valve	Volvo Excavator Rotary Overflow Valve	Volvo Excavator Main Relief/Control Valve
EC460	EC210 EC240	EC290	EC460 EC460LC
CMPV-D013			
			
Volvo Excavator Main Relief/Control Valve			
EC360B			
VOE 14552973			

## Volvo EXCAVATOR PARTS---Wire Harness, Motor Parts

CMPV-E001	CMPV-E002	CMPV-E003	CMPV-E004
			
Volvo Cable Wiring Harness	Volvo Excavator Wiring Harness	Volvo Excavator Wiring Harness	Volvo Excavator Cable Wiring Harness
EC210C L60F L70F L90F EW160C EC235C	EC290	D7E	EC210
22243151/ 22068267	20814758/ 22041209		
CMPV-E005	CMPV-E006	CMPV-E007	CMPV-E008
			
Volvo Excavator Wiring Harness	Volvo Excavator Wiring Harness	Volvo Excavator Wiring Harness	Volvo Wiper Motor
	EC210		EC120B EC240 EC160B EC360B
14631808	VOE20886142	VOE 88850634	VOE14508630
CMPV-E009			
			
Volvo Universal Motor Blower			

## Volvo EXCAVATOR PARTS----Engine parts (Pump, Turbocharger, Injector)

CMPV-F001	CMPV-F002	CMPV-F003	CMPV-F004
			
Volvo Excavator Water Pump	Volvo Excavator Fuel Pump	Volvo Excavator Fuel Pump	Volvo Excavator Fuel Injection Pump
EC240B EC210 EC290B Engine No. D7D	EC140B EC210B	EC210	EC290
VOE20459004/ VOE21404502	VOE20518337/VOE21019945/VOE21620 116 04290596/04294704/04294706	VOE 21584586	
CMPV-F005	CMPV-F006	CMPV-F007	CMPV-F008
			
Volvo Engine Turbo Turbocharger	Volvo Turbo Turbocharger	Volvo Turbo Turbocharger	Volvo BOSCH Fuel Injector
EC210B Engine No.D6D	EC240B EC240BLC EC290B	EC290B D7E	EC210B
	VOE21109241 (DEUTZ 0429 4738)	20873313/ 20459239/ 15096757	VOE 20798683 BOSCH 0445120067
CMPV-F009	CMPV-F010	CMPV-F011	CMPV-F012
			
Volvo Deutz Fuel Injector	Volvo Fuel Injector	Volvo BOSCH Fuel Injector	Volvo Fuel Injector
EC210	D16E EC700BLC	EC210B EC290B D6D	EC210 EC240 EC290 EC330BLC EC330 EC360
04290987/ 04290986	9098404	BOSCH 0445120066	VOE 20440388
CMPV-F013	CMPV-F014		
			
Volvo Injector Roller	Volvo Fuel Injector		
EC140B EC160B EC240B EC290B D7D	D12D		
VOE 11700392	VOE 20847327		



### Volvo EXCAVATOR PARTS----Seal kit

CMPV-G001	CMPV-G002	CMPV-G003	CMPV-G004
			
Volvo Boom Cylinder Seal Kit	Volvo Track Adjuster Seal Kit	Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit
EC210B	EC210BLC	EC210BLC	EC210BLC
14589129			
CMPV-G005	CMPV-G006	CMPV-G007	CMPV-G008
			
Volvo Bucket Cylinder Seal Kit	Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit	Volvo Bucket Cylinder Seal Kit
EC210BLC	EC210LC	EC210LC	EC210LC
CMPV-G009	CMPV-G010	CMPV-G011	CMPV-G012
			
Volvo Swing Motor Seal Kit	Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit	Volvo Bucket Cylinder Seal Kit
EC240B	EC240BLC	EC240BLC	EC240BLC
14556030 14526214			
CMPV-G013	CMPV-G014	CMPV-G015	CMPV-G016
			
Volvo PPC Seal Kit	Volvo Excavator Overhaul Full Gasket Kit	Volvo Control Valve Seal Kit	Volvo Main Pump Seal Kit
EC330B	EC360B Engine D12	EC460LC	EC460LC
			
Volvo Arm Cylinder Seal Kit	Volvo Boom Cylinder Seal Kit	Volvo Bucket Cylinder Seal Kit	GIANT ORING BOX
EC460LC	EC460LC	EC460LC	Volvo Hyundai Doosan

### Volvo EXCAVATOR PARTS---Others

CMPV-H001	CMPV-H002	CMPV-H003	CMPV-H004
			
Volvo Bushing	Volvo Coupling	Volvo Coupling	Volvo EC Fuel Inlet Metering Valve
EC240B EC210B	EC240B EC210B	EC240B EC210B	
VOE14512696	VOE14504230	VOE14531072	0928400670
CMPV-H005	CMPV-H006	CMPV-H007	CMPV-H008
			
Volvo Key Fuel	Volvo Fuel Cap Diesel Fuel Tank	Volvo Water Tank	Volvo Coupling
	EC210B	EC240BLC EC210B	EC210B
	14528922	15047209	41515827
CMPV-H009	CMPV-H010	CMPV-H011	
			
Volvo Fuel Pressure Regulator	Volvo Rotary Knob, Throttle Knob	Volvo Selector Unit Throttle Knob	
EC210BLC EC240B EC290BLC	EC210B		
VOE21103266	VOE 14542152	14659775/ VOE14659775	